

DESCRIPTIONS

CM1 series Indicator has been designed in simple function and 4 digital 20.0mm LED displays with economic cost.

They are can be programmed by tack switches that are hidden in backside of front bezel.

They are also available 1 option of 2 Relay outputs, 1 Analogue output or 1 RS485(Modbus RTU Mode) interface with versatile functions such as control, alarm, re-transmission or communication for a wide range of industrial applications.

FEATURE

Common Function

- Optional output available for one of 2 relay, analogue or RS485
- Operation key built (in the front panel), can be set to display range;terminal straight into the design, no poor contact questions;installation depth of only 72mm
- CE CE Approved (EMC/EMI/LVD) & RoHS

[CM1-VA ECONOMIC VOLT/CURRENT Meter]

- Measuring AC / DC Voltage 0~50.00mV/~600.0V / Current 0~1.999mA/~10.00A

[CM1-PR 4 Digital DC Process Meter]

- Measuring DC voltage 0(1)~5V/~10V OR DC current 0(4)~20 mA/0~10 mA
- Purchasing power to stimulateadditional DC24V, 30mA

[CM1-RL 5 Digital RPM/Line speed Meter]


- Measuring Frequency input 0.01Hz~6KHz , Do not need to specify the frequency range ; Input Model(NPN \ PNP \) and Pulse level can be switch by DIP
- Optional excitation power DC12V, 30mA





APPLICATIONS

- **CM1-VA** High and low voltage power disk / motor control panel - Overload /mechanical voltage and current display / test equipment voltage / current display, alarm protection and computer connections
- **CM1-PR** Process in a variety of sensors (pressure transmitters, temperature and humidity transmitter ...) to do live shows,and computer alert to protect the connection
- **CM1-RL** Mechanical speed of the motor / speed limit on-sitedisplay, alarm protection and computer connections


ORDERING INFORMATION: Please confirm specifications prior to installation







INSTALLATION

Please check the specification, wire diagrams and functions on the label of the meter before installation..



DIMENSIONS & Panel Cut Out

INSTALLATION



Wiring Diagram

Please check the voltage of power supplied first, and then connect to the specified terminals. It is recommended that power supplied to the meter be protected by a fuse or circuit breaker. ◦

⚠ Remark · PT can not short in secondary ; CT can not open in secondary

⚠ Wiring may be changed, follow the wiring diagram on the instrument wiring

Terminals

20A/300Vac, M3.5, 12~22AWG;

Max torque: 13Kg-cm


(If the use of electric driver, please adjust the torque electric driver)



Input Signal Connection

Connect the input signal, use twisted-pair isolation ◦


CM1-VA Input Connection




⚠ Remark:
PT can not short in secondary ;
CT can not open in secondary

CM1-PR Input Connection


2-wire sensor transmitter connection




4(0)~20mA Input Connection




3-wire sensor transmitter connection



0~10V Input Connection



Sensor Input Connection



DIP switch to switch the input mode and pulse level but must be consistent with the input signal

DIP D-S	1	2	3	4	5
NPN	ON				
PNP		ON			
CONTACT	ON				ON
Voltage pulse 5V _P				ON	
Voltage pulse 12V _P					ON
Voltage pulse 24V _P					ON

DIP switch position cut to the bottom, behalf the DIP switch is ON

Terminals:
20A/600Vac, M3.5, 1.2~3.5mm² (22~12AWG)



Option output terminal




Power&Input Terminals



If power supply noise interference, install an isolation transformer. ◦

Power Supply




Output (one output available of Relay, Analogue or RS485)


Relay output



Analogue Output




RS485 port



Max. Distance: 1200M
Terminate Resistor
(at latest unit):
120~300ohm/0.25W
(typical: 150ohm)

OPERATING

FRONT PANEL



Number screen:

- 8888.8: red high-brightness LED for 5 digital present value.

Output LED:

- Relay Energized:** 2 square red LED
 - RL1 display when Relay 1 energized
 - RL2 display when Relay 2 energized; ;
- COM RS485 Communication:** 1 square orange LED; COM will flash when the meter is receive or send data, and COM flash quickly means the data transient quicker. °

- Stickers:** Each instrument will be attached to the relay function are engineering units stickers and stickers ; Please choose according to site usage label affixed to the front panel functions and units °

OPERATING KEY:

*Please access to the Programming Level to check and set the parameters when users start to run the meter

- Operating Key:** 4 keys for Enter(Function) / Shift(Escape) / Up key / Down key
- The meter has designed operation similar as PC's and . In any page, press key means "enter" or "confirm setting", and press key means "escape()" or "shift".
- In Programming Level, the screen will return to Measuring Page after do not press any key over 2 minutes, or press for 1 second.

	Function Index	Setting Status
(=) Enter/Fun key	(1) In any page, press to access the level or function index (2) From the function index to access setting status	(3) Setting Confirmed, save to EEPROM and go to next function index
(=) Shift key	(1) In measuring page, press for 1 second to access user level. (2) In function index, press for 1 second to go back upper level. (3) In function group index, press for 1 second to go back measuring page	(4) In setting status, press to Shift the setting position. (5) In setting status, press for 1 second to abort setting and go back this function index.
(=) Up key	(1) In function index, press to go back to previous function index	(2) In setting status for function, press to select function (3) During number Setting, press can roll the digit up
(=) Down key	(1) In Function Index Page, press will go to the next Function Index Page.	(2) In setting status for function, press to select function (3) During number Setting, press can roll the digit down.

Stickers:

- Hi Hi Action Lo Lo Action
- Hi.H Hi Action &Hold Lo.H Lo Action &Hold
- Unit stickers:** 106 kinds


~μA	~mA	~A	~KA	=μA	=mA	=A	=KA		
~μV	~mV	~V	~KV	=μV	=mV	=V	=KV		
A hr	A min	A sec	A rms	V rms	A/mA	W/A	Var/A		
W	KW	MW	WH	KWH	MWH	W/WH	W/Var		
Var	KVar	MVar	QH	KQH	MQH	COS θ	Var/VarH		
VA	KVA	MVA	VAH	KVAH	MVAH	θ	KVarH		
Hz	PF	KA	KV	KHz	MVarH	KM/hr			
A	mA	V	mV	Ω	KΩ	°C	°F	%RH	
RPM	M/min	Y/min	F/min	M/sec	%	°	MΩ		
Kg/cm ²	Bar	mmH ₂ O	mmHg	KPA	mmAq	PSI	mBar	PA	
M ³ /min	ml/min	Ton/D	L/min	Torr	M ³ /hr	Kg-cm	cmHg		
mm	cm	M	KM	ft	Yard	ppm	ppb	C.C	
g	KG	Ton	T-cm	NT-cm	PH	MPM	L		

- Operating Key:** 4 keys for Enter(Function) / Shift(Escape) / Up key / Down key


Pass Code:

4-digit password to set; To enter the parameter screen, you must enter the correct password, please remember the password. If you forget the password, please contact the company. This password can be in steps [P.C o d E] to change


OPERATING DIAGRAM (The detail description of operation, please refer to operating manual.)




B. RELAY GROUP




D. ANALOGUE OUTPUT GROUP



E. RS485 GROUP



■ OPERATING DIAGRAM (Into the User Level)



INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
POWER ON			Please check the specification and wiring diagrams firstly.	
88.88.8.8		Self-diagnosis	(LED All bright)	
C n l u A		Model C n l u A : Voltage / Current C n l P r : DC 0~10V/0~20mA C n l r L : RPM / Line speed		
u E r 1.0		Firmware version		
9999		Measuring Page		
		Press for 1 second return to Measuring Page		
0-01		n in (PV Minimum storage): the Minimum value of PV saving When the meter power is turned on, both began to record shows that the minimum value had occurred ; Except by [n St] (step 0-03) to perform cleanupfunctions or instrument off; otherwise been recordedand stored automatically update the new value.	Checking only	
0-02		n R y (PV Maximum storage): the Maximum value of PV saving When the meter power is turned on, both began to record shows that the maximum value has occurred;Except through [n St] (step 0-03) to perform cleanupfunctions or instrument off; otherwise will always be recorded and stored the new value is automatically updated	Checking only	
0-03		n r St (Maximum & Minimum reset): Reset the saved value of Maximum & Minimum Be stored maximum / minimum values, this function can be removed. This meter will be removed immediately after the relatively new storage maximum/ minimum values °	Setting Range: YES / NO YES (Yes): Clear the stored maximum / minimum value NO (No): Does not clear the stored maximum / minimum values & Cycle selection Determine	
NEXT				

0-04		rY 1SP (Set-point of relay 1): Relay 1 Set-point	Setting Range: -1999~9999 (CM1-RL:-19999~99999) ◀ Shift ▲ Up ▼ Down Enter
0-05		rY 2SP (Set-point of relay 2): Relay 2 Set-point	Setting Range: -1999~9999 (CM1-RL:-19999~99999) ◀ Shift ▲ Up ▼ Down Enter
0-06		rY rSt (Reset relay hold): Reset for energized Latch of Relay	Setting Range: NO/YES ◀ Shift ▲ Up ▼ Down Enter
0-07		Cn lAr: model of the meter firmware version Cn lAr (CM1-VA): Voltage / Current Cn lPr (CM1-PR): DC 0~10V/0~20mA Cn lRl (CM1-RL): RPM / line speed uEr 1.0 (Ver 1.0): firmware version	Checking only ; The model number and software version will differ according to different models
0-01		Cyclic to first page Under the screen in any of the above	Press for 1 sec. back to Measuring

Into the Programming Level


INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
		Measuring display		
		Pass code screen	To change the password set to Step A-8, and do not forget the password	
		Pass code input		

Press Into Programming Level








Press 1 Sec Can back to Measuring display

Input parameter group


CM1-VA/CM1-PR



INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
		Pass code input		
		Input function group promptscreen		
		Any of the following screen Press ◀ 1sec , back Input group		
A-1		P.dP (Decimal Point of PV): Decimal Point of PV	Setting Range: 0 / 00 / 000 / 0000 & Cycle selection Enter	
A-2		Lo.SC (Low scale): Low scale of PV	Setting Range: -1999~9999 (CM1-RL:-19999~99999) Shift Up Down Enter [SCALE] Default: [Lo.SC]: 000, [H.SC]: 5000 [H.SC] Changed: [Lo.SC]: 2500, [H.SC]: 9999 	
A-3		H.SC (High scale): High scale of PV	Setting Range: -1999~9999 (CM1-RL:-19999~99999) Shift Up Down Enter	
		NEXT		





<p>A-4</p>  <p>LoCut</p> <p>0000</p> <p>00</p> <p>0000</p> <p>00 10</p> <p>FUN ENT NEXT</p>	<p>LoCut (Low Cut): Low Cut the PV</p> <p>Low Cut set to be +0.50</p>  <p>Low Cut is set for 0.50, if the PV is from -0.50~+0.50, that display will be 0.</p>	<p>Setting Range: -1999~9999 counts</p> <p>Shift Up Down FUN ENT Enter</p> <p>Low Cut set to be -0.10</p>  <p>Low Cut is set for -0.10, if the PV is under (≤ -0.10), that display will be -0.10.</p>
<p>A-5</p>  <p>RuG</p> <p>5</p> <p>5</p> <p>09</p> <p>09</p> <p>99</p> <p>FUN ENT NEXT</p>	<p>RuG (Average): Average update for PV</p> <p>The meter's sampling is 15cycle/sec If the [RuG](Average) set to be 3 to express the display update with 5 times/sec. The meter will calculate the sampling 1-3 and update the display value. At meantime, the sampling 4-6 will be processed to calculate.</p>	<p>Setting Range: 1(NONE)~99 times</p> <p>Shift Up Down FUN ENT Enter</p>
<p>A-6</p>  <p>nRuG</p> <p>8</p> <p>8</p> <p>09</p> <p>09</p> <p>99</p> <p>FUN ENT NEXT</p>	<p>nRuG (Moving Average): Moving Average update for PV</p> <p>In the first updated display value will be same as average function. In the next updated display value, the function will get the new fourth sample (sample 4) then throw away the first sample (sample 1) that the newest 3 samples(sample 2,3,4) will be calculated for the updated display value.</p>	<p>Setting Range: 1(NONE)~99 times</p> <p>Shift Up Down FUN ENT Enter</p>
<p>A-7</p>  <p>dFilt</p> <p>8</p> <p>8</p> <p>09</p> <p>09</p> <p>99</p> <p>FUN ENT NEXT</p>	<p>dFilt (Digital filter): Digital filter</p> <p>The digital filter can reduce the influence of spark noise by magnetic of coil. If the values of samples are over digital filter band(fixed in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.</p>	<p>Setting Range: 1(NONE)~99 times</p> <p>Shift Up Down FUN ENT Enter</p>
<p>A-8</p>  <p>PCode</p> <p>1000</p> <p>0000</p> <p>1009</p> <p>...</p> <p>1999</p> <p>9999</p> <p>FUN ENT NEXT</p>	<p>PCode (Pass Code): Pass Code setting for access to programming level</p> <p>Please remind and write down the new pass code so that access to programming level.</p>	<p>Setting Range: 0000~9999</p> <p>Shift Up Down FUN ENT Enter</p>

CM1-RL




INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
Pass Code		Pass code input		
↓ YES				
inPUt		Input function group promptscreen		
GrOuP				
FUN ENT ↓				
		Any of the following screen Press ◀ 1sec , back Input group		
A-1		PuTYP (PV type selection): DisplayType Line speed/RPM Selection The meter has a measurement line speed, RPM and frequency functions. Users can simply set the display purposes, the meter will start the function of the corresponding ◦	Setting Range: LnSPd Linearly Line Speed: ; rPn RPM: Revolution(s) Per Minute rPS (RPS): Revolution(s) Per Seconds Hz (Hz): Frequency kHz (kHz): Frequency & Cycle selection FUN ENT Enter r	
A-2-1		PuTYP selected (rPn / rPS) / (LnSPd) , the fun. will display PPr (Pulse/rotation): Input Pulse precedes set	Setting Range: 1~99999 ◀ Shift ▲ Up ▼ Down FUN ENT Enter	
NEXT				









A-2-2		EUnit selected (LnSPd) , the fun. will display EUnit (Engineer Unit): Line speed display unit selection	Setting Range: M/min CM/min Yd/min Ft/min Cycle selection Enter
A-轉速 2-3		Dia selected (LnSPd) , the fun. will display Dia (Diameter): Shaft diameter set	Setting Range: 0.0001~9.9999M(公尺) Shift Up Down Enter
A-3		Pudp: Decimal Point of PV ; There are two definitions for this setting: 1. If fun. setting is Auto , the Pudp set point for the relay output of decimal places set ; 2. If fun. setting is SEn or hAnUL , the Pudp set point for the relay output & PV of decimal places set ;	Setting Range: 0 / 00 / 000 / 0000 / 0.0000 Cycle selection Enter
A-4		Factor (Factor): Display scale factor ; Display value = calculated value x scale factor	Setting Range: 0.001~9.999 Shift Up Down Enter
A-5		LowCut (Low Cut): Low Cut the PV Low Cut setting +0.50 Low Cut setting -0.10 [LowCut] is setting 0.50 , when PV between -0.50~+0.50 , Display is "0" . [LowCut] is setting -0.10 , PV Less than equal to (<= -0.10) , Display is "-0.10" .	Setting Range: -19999~+29999 counts Shift Up Down Enter
A-6		Itand: Input Time Out Mode When the frequency is too low, this table shows the calculation based on this function to set the time zero value .	Setting Range: Auto (Auto): Automatic calculation zero display timo . hAnUL (Manual): Manually calculation zero display timo . Cycle selection Enter
A-7		Itand selected hAnUL , the Fun. display Itom (Input Time Out): Zero time setting . When the frequency is too low to display zero value (TIME OUT) time setting	Setting Range: 0.0 sec~999.9sec Shift Up Down Enter
NEXT			




<p>A-8</p> 	<p>RANGE :Display Range Mode</p>	<p>Setting Range:</p> <p>AUTO (Auto): Automatically adjust the decimal point position; according to the size of the input frequency, automatically switching the decimal point position ◦</p> <p>SEMI (Semi-Auto): Semi-automatic adjustment of the decimal point position; according to the size of the input frequency, automatically switching the decimal point position; but no more than set the value of decimal places decimal point position set ◦</p> <p>MANUAL (Manual): Fixed display range; display decimal point according to the set position when the input frequency exceeds full scale, it will display ovfl overflow ◦</p> <p>◀&▶ Cycle selection ENTER Enter</p>	
<p>A-9</p> 	<p>AVG (Average): Average update for PV The meter's sampling is 15 cycle/sec If the [AVG] (Average) set to be 3 to express the display update with 5 times/sec. The meter will calculate the sampling 1-3 and update the display value. At meantime, the sampling 4-6 will be processed to calculate.</p>	<p>Setting Range: 1 (None)~99 times</p> <p>◀ Shift ▲ Up ▼ Down ENTER Enter</p>	
<p>A-10</p> 	<p>dFILT :Digital filter The digital filter can reduce the influence of spark noise by magnetic of coil. If the values of samples are over digital filter band (fixed in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.</p>	<p>Setting Range: 0 (None)/1~99 times</p> <p>◀ Shift ▲ Up ▼ Down ENTER Enter</p>	
<p>A-11</p> 	<p>PCode (Pass Code): Pass Code setting for access to programming level Please remind and write down the new pass code so that access to programming level.</p>	<p>Setting Range: 0000~9999</p> <p>◀ Shift ▲ Up ▼ Down ENTER Enter</p>	

■ Relay function parameter group (If you do not specify this function, this group will not appear related functions)




INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
rELAY Group		Relay function group promptscreen	Any of the following screen Press ◀1 sec , Back to Relay function group	
B-1 rY5b	0000 00 9999	rY5b: Start band of Relay Output When the value exceeds the action does not start with, then the start-up delay time (Start delay time), the relay will start the PV value compared with the output set value Start Delay [rY.SP] [rY5b] [rY5d]	Setting Range: 0~9999 counts ◀ Shift ▲ Up ▼ Down FUN ENT Enter	
B-2 rY5d	0000 0000 9.999	rY5d: Relay Output start delay time	Setting Range: 0:00.0~9m:59.9s ◀ Shift ▲ Up ▼ Down FUN ENT Enter	
NEXT				







<p>B-3</p>  <p>FUNCTION NEXT</p>	<p>rY lnd :Relay 1 energized mode</p> <p>Hi / Lo Relay Energized</p>  <p>Relay Energized Latch & Reset</p> 	<p>Programmable:</p> <p>oFF (Turn off the Relay) : Turn off the Relay and indication LED.</p> <p>Lo (Low Level Energized) : Low Level Energized; Relay will energize when PV < Set-Point.</p> <p>Hi (High Level Energized) : High Level Energized; Relay will energize when PV > Set-Point.</p> <p>Hi.HLd / Lo.HLd (High / Low Level energized hold) : High / Low Level energize and latch; As the PV Higher (or lower) than set-point, the relay will be energized to latch except manual reset by from key in [User Level], front key function or terminals of E.C.I. closed</p> <p>▼&▲ Cycle selection FUNCTION Enter</p>	
<p>B-4</p>  <p>FUNCTION NEXT</p>	<p>rY lHY :Relay 1 Hysteresis</p> <p>Energized / De-energized Delay & Hysteresis</p> 	<p>Setting Range: 0~5000 counts</p> <p>◀ Shift ▲ Up ▼ Down FUNCTION Enter</p>	
<p>B-5</p>  <p>FUNCTION NEXT</p>	<p>rY lrd :Relay 1 energized delay time</p>	<p>Setting Range: 0:00.0~9(m):59.9(s)</p> <p>◀ Shift ▲ Up ▼ Down FUNCTION Enter</p>	
<p>B-6</p>  <p>FUNCTION NEXT</p>	<p>rY lFd :Relay 1 de-energized delay time</p>	<p>Setting Range: 0:00.0~9(m):59.9(s)</p> <p>◀ Shift ▲ Up ▼ Down FUNCTION Enter</p>	
<p>B-7</p>  <p>FUNCTION NEXT</p>	<p>rY 2nd :Relay 2 energized mode</p>	<p>Setting Range: the same as rY lnd</p> <p>oFF Lo Hi Hi.HLd</p> <p>Lo.HLd</p> <p>▼&▲ Cycle selection FUNCTION Enter</p>	
<p>NEXT</p>			

<p>B-8</p> 	<p>rY2HY</p> <p>0000</p> <p>5000</p> <p>FUN ENT NEXT</p>	<p>rY2HY:Relay 2 Hysteresis</p>	<p>Setting Range: 0~5000 counts the same as rY2HY</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>	
<p>B-9</p> 	<p>rY2rd</p> <p>0000</p> <p>9.999</p> <p>FUN ENT NEXT</p>	<p>rY2rd:Relay 2 energized delay time</p>	<p>Setting Range: 0:00.0~9分:59.9秒 the same as rY2rd</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>	
<p>B-10</p> 	<p>rY2Fd</p> <p>0000</p> <p>9.999</p> <p>FUN ENT NEXT</p>	<p>rY2Fd:Relay 2 de-energized delay time</p>	<p>Setting Range: 0:00.0~9分:59.9秒 the same as rY2Fd</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>	


Analogue Output Group (The group will not be displayed except the AO function is to be specified)



INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
Ao		AO GRIOP INDEX PAGE	In following pages, press for 1 second to return the AO GROUP INDEX PAGE.	
D-1	AoTyp R4-20 u0-10	AoTyp : Analogue Output type Analogue output type had been fixed in mA or V as customer ordering requested. Therefore, the type selection is only for the ranges in same type (Voltage or Current). ◦	Programmable: Voltage Output: u0-10 (0~10V) / u0-5 (0~5V) / u.1-5 (1~5V) Current Output: R0-10 (0~10mA) / R0-20 (0~20mA) / R4-20 (4~20mA) & Cycle selection Enter	
D-2	AoLS 00 5000	AoLS : Analogue Output relative Low Scale Ex. Output range set to be R4-20 (4~20mA) is relative to display 0~199.99 ; User can set the [AoLS] (AoLS) to be 5000 , At meantime, the output signal will be 4mA	Setting Range: -19999~29999 (CM1-RL:-19999~99999) Shift Enter SCALE Default: [LoSC]: 0.00, [H .SC]: 19999; Changed: [AoLS]: 50.00 (Relative Low), [AoHS]: 150.00 (Relative High) 0.00% 50.00% 100.00% OUTPUT	
NEXT				

<p>D-3</p> 	<p>FUN ENT</p> <p>19999</p> <p>15000</p> <p>FUN ENT NEXT</p>	<p>RoHS :Analogue Output relative High Scale</p> <p>Ex. Output range set to be R4-20 (4~20mA) is relative to display 0~199.99 ; User can set the [RoHS] (Ao.HS) to be 15000 , At meantime, the output signal will be 20mA ◦</p>	<p>Setting Range: -19999~29999 (CM1-RL:-19999~99999)</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>
<p>D-4</p> 	<p>FUN ENT</p> <p>00000</p> <p>-999</p> <p>FUN ENT NEXT</p>	<p>RoZro :Fine Zero Adjustment for Analog Output ;</p> <p>Users can get Fine zero Adjustment for analogue output by front key. Please connect standard meter to the terminal of analogue output for measuring the output value. To press the front key(up or down key) to adjust and check the output of meter. ◦</p>	<p>Setting Range: -1999~9999</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>
<p>D-5</p> 	<p>FUN ENT</p> <p>00000</p> <p>9999</p> <p>FUN ENT NEXT</p>	<p>RoSPn :Fine Span Adjustment for Analog Output ;</p> <p>Users can get Fine span Adjustment for analogue output by front key of the meter as like as [RoZro] (Ao.Zro).</p>	<p>Setting Range: -1999~9999</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>
<p>D-6</p> 	<p>FUN ENT</p> <p>nonE</p> <p>botH</p> <p>FUN ENT NEXT</p>	<p>P5CLR :Clear Fine Zero / Span Adjustment for Analog Output</p>	<p>Programmable:</p> <p>nonE(None): Do not clear</p> <p>RoZro(Ao.Zro): Clear low adjust</p> <p>RoSPn(Ao.SPn): Clear high adjust</p> <p>botH(both): Clear low & high adjust</p> <p>◀ Shift & ▲ Cycle selection FUN ENT Enter</p>
<p>D-7</p> 	<p>FUN ENT</p> <p>11000</p> <p>10000</p> <p>FUN ENT NEXT</p>	<p>RoLnt :Analog Output High Limit</p> <p>Display High: [LoSC]: 000, [H.SC]: 19999; output: [RoLS]: 5000 (Relative low), [RoHS]: 15000 (Relative High); [RoLnt]: 80.00% (Output limit setting)</p> 	<p>Setting Range: 0.00~110.00% of FS (CM1-RL has no the Fun.)</p> <p>◀ Shift ▲ Up ▼ Down FUN ENT Enter</p>

RS485 Group (The group will be hidden, if the relay function is not to be specify)



INDEX	Step	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
rS485 GrOUP FUN ENT		RS485 GROUP INDEX PAGE	In following pages, press for 1 second to return the RS485 GROUP INDEX PAGE.	
E-1 AdRES FUN ENT 001 255 FUN ENT NEXT		AdRES :Device number of the meter	Setting Range: 1~255 Shift Up Down Enter	
E-2 bAUD FUN ENT 9600 38400 FUN ENT NEXT		bAUD :Baud rate	Settable range: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 & Cycle selection Enter	
E-3 Pr tY FUN ENT nStb.2 EvEn FUN ENT NEXT		Pr tY :Parity	Programmable: nStb.1(n.Stb.1): None, 1 stop bit nStb.2(n.Stb.2): None, 2 stop bit odd(odd): odd EvEn(EvEn): Even & Cycle selection Enter	

FUNCTION DEFINE

Character Symbol

A b C d E F G H i J K L M
 R b [d E F G H , j l n
 n o P q r S t U v W X y Z
 n o P q r S t U v u y y p
 1 2 3 4 5 6 7 8 9 0 / .
 1 2 3 4 5 6 7 8 9 0 r .

Input & Scaling


Scaling Function

Setting Range: -1999~+9999 counts ;
 Users can set the parameters in the class is free to set the input signal display low [L.o.5C] (Low


Reading stable functions

Average Display update (Average):

Settable range:1~99 times ;
 Jittery Display caused by the noise or unstable signal. User can set the times to average the readings, and to get smoothly display. The meter's sampling is 15cycle/sec ; [AuC] set to be to express the display update with 5 times/sec



scale corresponding to the input lower limit) and show high values [H .5C] (High scale limit on the corresponding input); can be set to negative slope. Please refer to the following description



Moving Average update [n.A.U.C]:

Settable range : 1~99 times ;


Jittery Display caused by the reasons as like as noise or unstable signal. User can set the times to average the readings, and get smoothly display. ◦

The meter's sampling is 15cycle/sec ; [n.A.U.C] set to be 3 expressed ◦

the display update with 15 times/sec ,

In the first updated display value will be same as average function. In the next updated display value, the function will get the new fourth sample (sample 4) then throw away the first sample (sample 1) that the newest 3 samples(sample 2,3,4) will be calculated for the

updated display value.



Digital filter [d.F .L.L]

Settable range : 1~99 times ;

The digital filter can reduce the influence of spark noise by magnetic of coil.

If the values of samples are over digital filter band(fixed in firmware and about 5% of stable reading) 3

■ DISPLAY FUNCTIONS

■ Max / Mini recording

In order to review & trace the drifting PV, the meters will keep the values of maximum and minimum in [user level] during power on. User can reset the values by [$\bar{r}5t$] in [user level]. And it'll record new maximum and minimum value immediately after reset. ◦


■ Low Cut [LoCut]

Settable range from -19999~+29999 digits

Usually caused by interference, system factors or natural phenomena when there are small values near zero point, this feature displays zero ◦


If [LoCut] Setting is positive, it means that the displayed value in [LoCut] settings are within the absolute value is displayed as [LoCut] settings ;

Displayed $| \leq$ [LoCut] settings ,
and displayed all are [LoCut] settings ◦



If [LoCut] setting show that the value is negative in [LoCut] The following settings are displayed as [LoCut] setting ;

Display value \leq Set value display are all set value ◦



times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples. ◦

■ Relay Functions


CM1 series offer the 2 relay outputs ◦ Different control functions can be individually planned its related functions can be set at the button panel . Details are as follows ;

■ Relay energized mode [rY.nd]

selection : Hi / Lo


Hi (H) (Fig.1-①): Relay will be energized, when PV > Set Point

Lo (L) (Fig.1-②): Relay will be energized,



■ Relay energized delay and Relay de-energized delay

when PV < Set Point



Start delay band and Start delay time

The functions have been designed for

1. To avoid starting current of inductive motor (6 times of rated current) with alarm.
2. If the [rY.nd] relay energized mode had been set to be [Lo] (Lo) or [LoHLd] (Lo & latch). As the meter is power on and no input to display the "0" caused the relay will be energized. User can set a band and delay time to inhibit the energized of relay.


Start of band of Relay energized [rY5b] (Fig.2-1)

Settable range from 0~9999 Digits ;

When displaying the value exceeds started after no action, and then after startup delay time, the relay will start the PV value is compared with the set value output.

Start band [rY5d] (Fig.2-2)

Settable range: 0.0 Sec~9(m)59.9(s) .



Hysteresis [rY.HY] (Fig.3)

Settable range: 0~5000 Counts ;

As the display value is swing near by the set point to cause the relay on and off frequently. The function is to avoid the relay on and off frequently such as compressor.....etc.,

User can set a band to prevent from the relay on and off frequently.

Settable range: 0.0(s)~9(m)59.9(s) ;

This function is primarily to avoid instrument disruption or instability of input signals and relay misoperation .

- **Relay energized delay [rY.rd] (Fig.4-2):** When the value is reached when the conditions of the relay, the relay will delay action until ;

EX: Relay 1 setting

[rY.nd]: [Hi] ; [rY.rd]: [0050] ; [rY.SP]: [1000]

When (PV) over [100.1] (PV>[rY.SP]) and keep over 5 sec , Relay output will be Action (ON) .


- **Relay de-energized delay [rY.Fd] (Fig.4-3):**

If the display value to leave the relay of the conditions and set lasting more than this, the relay will reset

EX: Relay 1set

[rY.nd]: [Hi] ; [rY.Fd]: [0020] ; [rY.SP]: [1000]

When (PV) less than [999] (PV<[rY.SP]) and keep over 2 sec , Relay reset(OFF) .



Analogue Output Functions

Please specify the output type either 0~10V or 4(0)~20mA in ordering code. The output low and high can be programmable which it's related with various display values. Reverse slope output is decided by reversing point positions

- **Output range selection**

Voltage output specified, Programming :

: [0-10] (0~10V) / [0-5] (0~5V) / [1-5] (1~5V)

Current output specified Programming :

: [4-20] (4~20mA) / [0-20] (0~20mA) / [0-10] (0~10mA)


- **Output signal corresponds to display value**

Settable range: -19999~+29999/99999;

Low Output corresponds to Low display value

[R0L5]: Setting the Low Display value versus Low output range (as like as 4mA in [4-20]) .

Analogue Output relative High Scale) [R0H5]: Setting the High Display value versus High output range (as like as 20mA in [4-20])



*The interval between [R_{oHS}] and [R_{oLS}] should be with minimum over 50% of span; otherwise, it will reflect the less resolution of analogue output. ◦

■ Fine Zero & Span Adjustment for Analog Output Setting Range: -38011~27524;

Users can get Fine Adjustment of analogue output by front key on the meter. Please connect standard meter to the terminals of analogue output for measuring the output value. To press the front key(up or down key) of meter for adjusting and checking the output.

● Fine Zero Adjustment for Analog Output) [R_{oZr0}]: ;

When the analog output and display the corresponding minimum value (low) when there is error, this parameter can be operated directly to increase / decrease on the shift key or up / down keys to make fine-tuning


● Fine Span Adjustment for Analog Output) [R_{oSPn}]: ;

When the analog output and display the corresponding maximum value (high value) when there is error, this parameter can be operated directly to increase / decrease on the shift key or up / down keys to make fine-tuning.

■ High Limited for Analog Output) [R_{oLnt}]

Setting Range: 0.00~110.00%;

User can set the output in high limit to avoid destroying the receiver or protection system ◦



■ RS 485 Communication

CM1 series offers a Modbus RTU mode protocol. Communication speed up to 38400 bps; users can use RS485 set parameters, read the display. ◦

- Protocol: Modbus RTU Mode
- Baud Rate) [bAUD]: Programmable:1200/2400/4800/9600/19200/38400
- Data Bits: 8 bits
- Stop Bits: Programmable 1 bit or 2 bits
- Parity [Pr tY]: Programmable Even / Odd / None
- Device Number [Dr ES]: 1~255

■ ERROR MESSAGE

SELF-DIAGNOSIS AND ERROR CODE:		
DISPLAY	DESCRIPTION	REMARK
<div style="border: 1px solid black; padding: 2px; display: inline-block;">ouFL</div> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-left: 10px;">-ouFL</div>	1. input specification type (V / A / mA ..) are correct and match the signal range field?	Replace the correct match signal meter, or by mail to the company to modify the specifications
	3. Input signal exceeds the range (upper limit of +110% input specifications?)	A. Make sure the correct input signal B. Replace the correct match signal meter, or by mail to the company to modify the specifications
	4. Shows the corresponding input signal value is Less than L 0.5C ?	If the input signal Less than the corresponding display low(L 0.5C set value), the display will appear-ouFL A. Replace the correct match signal meter, or by mail to the company to modify the specifications
	4. Wiring access terminal and accessthe right solid?	A. Please confirm the wiring diagram on the instrumentwiring correct? And confirm whether a signal line (two lines) is not connected to the terminals ◦ B. Choose the appropriate crimp terminals to reduce thebad or the wiring is not strong ◦
Displayed value not correspond	1. Input signal range and field size is correct?	Replace the correct match signal meter, or by mail to the company to modify the specifications
	2. Shows the high value and low display settings are correct?	Re-confirm show high values [H 0.5C] (A-03) and show low[L 0.5C] (A-02) setting
Display unstable	1. Input signal isunstable (If there will be harmonics or noise components?)	A. For the rapid up and down continuously, try to set a larger[avg] (A-05) or [Mavg] (A-06) shows the average value ◦ B. For the moment the beat from time to time (the loadmovement caused by the coil), try setting a larger [dF 0.5C] (A-07) ◦ C. Connect signal wires should be away from the powerload, and use shielded twisted pair of metal mesh andmetal mesh shield termination of a metal chassis(g round) ◦
	3. Inputsignal stable, stable display	A. For the rapid up and down continuously, try to set a larger[R0.5C] (A-05) or [R0.5C] (A-06) shows the average value ◦ B. For the moment the beat from time to time (the loadmovement caused by the coil), try setting a larger [Dfilt] (A-07) ◦ C. Connect the power supply wire should be away from the power load, and use the isolating transformer D. If the electromagnetic field interference, please contact us ◦
Slow to respond to the displayed value		Set too much [avg] (A-05) or [Mavg] (A-06)

■ RS485(Modbus RTU Mode)

■ Modbus RTU Mode Communications protocol

一、 Read instructions by Function 03H (Read Holding Registers)

Request Data Frame ex: Read the display data (0000H start aWord)

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	01H	84H	0AH

Response Data Frame ex: reading"0"

SLAVE Address	FUNCTION	Byte count	Data Hi	Data Lo	CRC Lo	CRC Hi
01H	03H	02H	00H	00H	B8H	44H

Request Data Frame ex: Read 10 consecutive data points

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	0AH	C5H	CDH

Response Data Frame

SLAVE Address	FUNCTION	Byte count	Data(1) Hi	Data(1) Lo	Data(10) Hi	Data(10) Lo	CRC Lo	CRC Hi
01H	03H	14H	00H	00H	01H	00H	--	--

二、 Writed by Function 06H (Preset Single Register)

Request Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	05H	00H	01H	58H	0BH

Response Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	05H	00H	01H	58H	0BH

■ ADDRESS TABLE **Address number are Hexadecimal

CM1-VA/CM1-PR

■ User Level

Name	Address	Range	Explain	Initial	Write/Read	Note
PV	0000h	-1999~9999	Present Value		R	
\bar{n} in	0001h	-1999~9999	The Minimum of PV	0	R	
\bar{n} A \bar{h}	0002h	-1999~9999	The Maximum of PV	0	R	

■ Engineer Level

【 Input Group 】						
Name	Address	Range	Explain	Initial	Write/Read	Note
P \bar{u} dP	0003h	0~3	PV Decimal Point 0: 0000 1: 000.0 2: 000.0 3: 0.000	0	R/W	
L \bar{o} S \bar{C}	0004h	-1999~9999	Low Scale	0	R/W	
H \bar{H} S \bar{C}	0005h	-1999~9999	High Scale	9999	R/W	
L \bar{o} C \bar{u} t	0006h	-1999~9999	Low Cut	0	R/W	
A \bar{v} g	0007h	1~99	Average	5	R/W	
\bar{n} A \bar{v} g	0008h	1~99	Moving Average	8	R/W	
d \bar{F} i \bar{L} t	0009h	1~99	Digital Filter	8	R/W	
P \bar{C} o \bar{d} e	000Ah	0000~9999	Pass Code	1000	R/W	

【RS485 Group】						
Name	Address	Range	Explain	Initial	Write/Read	Note
AdrES	000Bh	1~255	RS485 address	1	R/W	
bRUD	000Ch	0~5	RS485 baud rate 0:1200 1:2400 2:4800 3:9600 4:19200 5:38400	4	R/W	
Pr tY	000Dh	0~3	RS485 parity 0: n-8-1 1: n-8-2, 2: odd-8-1, 3: even-8-1,	1	R/W	

CM1-RL

■ User Level

Name	Address	Range	Explain	Initial	Write/Read	Note
PV	0000h	0~99999	Present Value (*High word)		R	
	0001h		Present Value (*Low word)			
n in	0002h	0~99999	The Minimum of PV (*High word)	0	R	
	0003h		The Minimum of PV (*Low word)			
nRY	0004h	0~99999	The Maximum of PV (*High word)	0	R	
	0005h		The Maximum of PV (*Low word)			

■ Engineer Level

【Input Group】						
Name	Address	Range	Explain	Initial	Write/Read	Note
Pu.tYP	0006H	0~4	Choose display type: wire-speed / speed / frequency 0: Linear Speed 1: RPM 2:RPS3: HZ 4 : KHZ	0	R/W	
PPr	0007h	1~99999	Input Pulse	1	R/W	
	0008h					
E.U n t	0009h	0~3	Straight line speed display unitselection 0: M/min 1: CM/min 2:Yard/min 3: Feet/min	0	R/W	
d r n t	000Ah	0.1000~9.9999(M)	Shaft diameter	1000	R/W	
	000Bh					
dP	000Ch	0~4	Decimal point 0:00000 1:0000.0 2:000.00 3:00.000 4:0.0000	0	R/W	
FActr	000Dh	0.0001~9.999	Display factor	1000	R/W	
LoCUt	000Eh	-19999~19999	Low Cut	0	R/W	
t o n d	00Fh	0~1	Input signal time out model 0: Auto 1: Manual	0	R/W	
t o	0010h	1~9999(x0.1Sec)	time out setting	10	R/W	
AUG	0011h	1~99	Average	1	R/W	
dF iL t	0012h	1~99	Digital filtering	5	R/W	
PCode	0013h	0000~9999	Pass Code	1000	R/W	
【RS485 Group】						
Name	Address	Range	Explain	Initial	Write/Read	Note
AdrES	0014h	1~255	RS485 Station Address No.	1	R/W	
bRUD	0015h	0~5	RS485 Communication rate 0:1200 1:2400 2:4800 3:9600 4:19200 5:38400	3	R/W	
Pr tY	0016h	0~3	RS485 Parity 0:n-8-1 1:n-8-2 2:odd-8-1 3:even-8-1	1	R/W	

■ DISCLAIMS

The information in this manual has been carefully checked and is believed to be accurate. ADtek Instruments Co., Ltd. assumes no responsibility for any infringements of patents or other rights of third parties, which may result from its use.

ADtek assumes no responsibility for any inaccuracies that may be contained in this document, and make no commitment to update or to keep current the information contained in this manual.

ADtek reserves the right to make improvements to this document and/or product at any time without notice.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form of or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of ADtek Instruments Co., Ltd.

■ TRADEMARK

The names used for identification only maybe registered trademark of their respective companies.

Copyright © 2008 ADtek Instruments Co., Ltd. All rights reserved.

Printed in Taiwan.

Welcome to visit our online

www.adtek.com.tw www.csec.com.tw