

CS1-VA	VOLTAGE / CURRENT METERS
CS1-PR	DC SIGNAL (20mA/10V) INDICATOR
CS1-SG	STRAIN GAUGE / LOAD CELL INDICATOR
CS1-PM	POTENTIOMETER INDICATOR
CS1-RS	RESISTANCE(2 W) INDICATOR
CS1-T	TEMPERATURE INDICATOR

OPERATION MANUAL

DESCRIPTION

For the various measuring requirement, the CS1 series indicator provide simple and low cost with high accuracy measurement, display, control or communication (Modbus RTU mode) such as AC voltage/Current, DC process signal 0~10V/4~20mA, Strain Gauge/Load Cell, Potentiometer, Resistance, Temperature and so on.

They have been designed optional 1 of 3 kinds for 1 Relay, 1 Analogue or 1 RS485 port with flexible display function such as max/mini hold, PV hold relative PV.....etc that very useful in testing equipment and others.

FEATURES

- 1 relay, 1 Analogue output or RS 485 communication port can be selected one in option
- Relay for Hi / Lo energized with Start Delay / Hysteresis / Energized & De-energized Delay / Relay Energized Latch...etc functions
- CE Approved

[CS1-VA VOLT / CURRENT METER]

- Measuring Voltage 0~600V or Current 0~10A ; DC / AC / TRMS
- Accuracy: AC: $\pm 0.1\%$ f.s.; DC: $\pm 0.04\%$ f.s.; Display Range: -19999~+29999

[CS1-PR DC SIGNAL INDICATOR]

- Measuring DC 0~10V or 0(4)~20 mA in one indicator(input code: AV)
- Accuracy: $\pm 0.04\%$ f.s.; Display Range: -19999~+29999

[CS1-SG S TRAIN GAUGE INDICATOR]

- Measuring ranges of Load Cell or Strain Gauge from 0~1.0/~2.0/~4.0 mV/V or 0~10.0/~20.0/~40.0 mV/V and specified with excitation supply DC 5V or 10V, 40mA
- Accuracy: $\pm 0.04\%$ f.s. ; Display Range: -19999~+29999
- Field calibration of load cell or strain gauge to meet the system requirement with high/low calibrations which it saved test time and keep accuracy

[CS1-PM POTENTIOMETER INDICATOR]

- Measuring Potentiometer 0~50Ω/~2.0KΩ; 0~2.0KΩ/~100.0KΩ (3 wire)
- Accuracy: $\pm 0.04\%$ f.s. ; Display Range: -19999~+29999
- Field calibration of potentiometer to meet the system requirement with high/low calibrations which it saved test time and keep accuracy

[CS1-RS RESISTANCE INDICATOR]

- Measuring Resistance 0~200.00Ω/2000.0Ω/20.000KΩ/200.00KΩ (2 wires)
- Accuracy: $\pm 0.04\%$ f.s. ; Display Range: -19999~+29999
- Field calibration of resistance to meet the system requirement with high/low calibrations which it saved test time and keep accuracy

[CS1-T TEMPERATURE INDICATOR]

- Measuring Pt100Ω; T/C: K,J,E,T(the range will be fix, please specified the exactly input type in ordering)
- Accuracy: Pt100: $\pm 0.1\%$ f.s.; T/C: $\pm 0.2\%$ f.s.; Display Range: -19999~+29999(according to the seneor type)



APPLICATIONS

- Models
 - CS1-VA Switch Boards / Motor Control / Machinery / Testing Equipments
 - CS1-PR Machinery Control / Process Control Systems for pressure, level,.....sensing transducers Automation System / Testing Equipments
 - CS1-SG Weighting indication, control and Alarm / Machinery Control / Tension and others test equipment
 - CS1-PM Position indication, control and Alarm / Machinery Control / Angle of Value Control
 - CS1-RS Resistance test as like as coil / Tap of transformor indication
 - CS1-T Temperature measuring
- Functions
 - Safety & Protection Hi or Lo alarm and latch([H .HLd] / [LoHLd])
 - Testing & Measuring Maximum/Minimum hold([MRH] / [MinH]), PV hold([PvHLd]), Relative PV/Tare/ Δ PV([RELPU]), Field calibration with sensor
 - Remote Monitoring RS485 communication port, Display function([5485]),

FUNCTION DEFINE

Character Symbol

A	b	C	d	E	F	G	H	i	J	K	L	M
R	b	[d	E	F	G	H	,	U	Y	L	n
n	o	P	q	r	S	t	U	v	W	X	y	Z
n	o	P	q	r	S	t	U	u	y	y	?	
1	2	3	4	5	6	7	8	9	0	/	.	
i	2	3	4	5	6	7	8	9	0	?	.	

Display Functions


- Max / Mini recording:**
In order to review & trace the drifting PV, the meters will keep the values of maximum and minimum in [USER LEUEL] during power on.
- Display function [dSPLY] for display screen**
The [dSPLY] function in [INPUT GROUP] can be set to show present value [Pv], Maximum Hold [MRHd] or Minimum Hold [MinHd] or Remote display by RS485 command [5485]. Please refer to following for detail.

Input & Scaling

Input type [R tYP] for CS1-PR
Programming range: Voltage:0~10V/0~5V/1~5V;
Current: 4~20mA/0~20mA/0~10mA
 It supports dual type input 0~10V and 0(4)~20mA between 3 terminals in one meter. Please specify the ordering code AV for input range. And, programming the function [R tYP] to co-ordinate with the input range and wiring terminals.

Scaling Function [LoSC] & [H .SC]

Setting the [LoSC] (Low scale) and [H .SC] (High scale) in [INPUT GROUP] are relative to input signal. Reverse scaling will be done too. Please refer to the figure as below,



*Lower display resolution may caused by more narrow scale.


Present value [Pv]

Display screen will show the value that is relative to input and [LoSC](Low scale) and [H .SC] (High scale) setting.

Max. Hold [MRHd] or Mini. Hold [MinHd] for PV

When the [dSPLY] function in [INPUT GROUP] set to be [MRHd](Max. Hold) or [MinHd](Mini. Hold), that the meter will still display the values of PV in maximum(or minimum) and the relative square orange LED will be bright during power on, until manual reset by front key in [USER LEUEL] or Down Key function has been done. The meter will update immediately new max./mini. values after press Down Key again.

Please paste the sticker on the right side of orange square LED to identify the status of display.



Remote display by RS485 command


In past, The meter normally receive 4~20mA or 0~10V from AO card or BCD card of PLC. We built-in a new solution by RS485 which it can save costs of AO and wiring connecting to PLC simultaneously.

When the [dSPly] function set to be **[5485]**, the LED display no longer appear the input signal on the meter then the PV screen will show the data from RS485 command.

PV(Present value) Hold [PuHld]

When the [dNPEY](Down key function) set to be **[PuHld]**(PV Hold) function in [INPUt GROUP], The display will be hold, when the down key has been pressed until the down key pressed again.

Please paste the sticker **[ECl PV.H]** on the right side of green square LED of ECl to identify the status of display.




Low Cut [LoCut]


Settable range from **-19999~+29999** digits.

The users can set the value range.

- 1)if set the positive value (X1) here to display "0" which it expressed to be low-cut the PV between "+X1 (plus)" & "-X1(minus)" /absolute value $PV < | \text{Setting value (X1)} |$, the display will be shown 0
EX: Low Cut is set for 0.50. If the display is from $-0.50 \sim +0.50$, that will be 0.



- 2)if set the negative value (X2) here to display "X2" which it expressed to be low-cut the PV that it's under the X2 setting value;
 $PV < \text{Setting value}(X2)$, the display will be shown X2.
EX: Low Cut is set for -0.01. If the display is < -0.01 , and all the display will be -0.01.




Digital Fine Adjustment [PuPro] & [PuSPn]

Settable range from **-19999~+29999** ;

Users can get "Fine Adjustment PV" by front key on the meter for lower and/or higher points. "Just Key-In" the value, if user wants to show the value in input signals currently.

Especially, the [PuPro] & [PuSPn] are not only in zero & span of PV, but also randomly lower point in function [PuPro] & randomly higher point in function [PuSPn]. The meter will be auto-linearization for full scale.

The adjustment can be cleared in function [P5CLR].



Front Key Functions

Users can set the **[Down Key]** of front panel to be the functions as like as Relative PV(Tare) / PV Hold / Reset for max(mini) hold / Reset for relay energized latch.

Ex. The [dNPEY] function set to be **[REL.PU]** in [INPUt GROUP]. When user presses **[Down Key]**, the PV will show relative value until press **[Down Key]** again.

Reading Stable Functions


Average Display update

Settable range: **1~99** times;

Jittery Display caused by the noise or unstable signal. User can set number to average the readings to get smoothly display.

Remark: The higher average setting will impact the response time of Relay and Analogue output slower.

The meter's sampling is 15cycle/sec. If the [AVG](Average) set to be **[3]**, the meter will express the sampling 3 readings and calculating the average then update the display once. At meantime, the display update will be 5 times/sec.




Moving Average update

Settable range: 0(no function)/1~10 times;

Jittery Display caused by the reasons as like as noise or unstable signal. User can set number to average the readings, and get smoothly display.

Remark: The higher moving average setting wouldn't impact the response time of Relay and Analogue output slower after first 3 samples.

The meter's sampling is 15cycle/sec. If the $[r_{MA}]$ (Moving Average) set to be $[3]$, in the first cycle will be same as average function. In following cycle, the function will get a new fourth reading and throw away first reading to be newer 3 reading, and calculating the average then update display. At meantime, the display update will be 15 times/sec.




Digital filter [dF, L, E]

Settable range from 0(None)/1~99 times.

The digital filter can reduce the influence of spark noise by magnetic of coil.

If the values of samples are over digital filter band(fixed in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.




Relay Functions

CS1 series offer the 1 relay output with flexible and versatile functions. They can be programmed in $[r_{ELAY}]$ $[r_{OP}]$. Please refer to the description as following;

Relay energized mode Hi / Lo / Hi.HLD / Lo.HLD

- **Hi(Fig.1-①)** ($[H]$): Relay will be energized, when PV > Set Point
- **Lo(Fig.1-②)** ($[Lo]$): Relay will be energized, when PV < Set Point




Hi alarm & latch / Lo alarm & latch (H.HLD / Lo.HLD)

The relay energized with latched function is for electrical safety and human protection.

For example, a current meter relay installed for the over current alarm of motor. Generally, over current of motor caused by over load, mechanical dead lock, aging of insulation and so on. Above cases will alarm in the meter, if the user doesn't figure out the real reason and re-start the motor. It may damage the motor. The functions of Hi.HLD & Lo.HLD are designed must be manual reset the alarm after checking out and solving the issue. It's very important idea for electrical safety and human protection.


As the PV Higher (or lower) than set-point, the relay will be energized to latch except manual reset by from key in $[user\ level]$ or reset by down key, if the $[dn\ key]$ function in $[r_{PUT\ L\ E\ U\ E\ L}]$ has been set to $[Yr5t]$.



Start delay band [rY5b] and Start delay time [rY5d]

The functions have Been designed for,

- To avoid starting current of inductive motor (6 times of rated current) with alarm.
- If the $[r_{Y_nd}]$ relay energized mode had been set to be $[Lo]$ (Lo) or $[Lo.HLD]$ (Lo & latch). As the meter is power on and no input to display the "0" caused the relay will be energized. User can set a band and delay time to inhibit the energized of relay.
- **Start band [rY5b] (Fig.2-①):**
Settable range from 0~9999 Digits
- **Start delay time [rY5d] (Fig.2-②):**
Settable range from 0.0(second)~9(minutes)59.9(seconds);



■ **Hysteresis [rY_HY] (Fig.3-①)**

Settable range from 0~5000 Digits

As the display value is swing near by the set point to cause the relay on and off frequently. The function is to avoid the relay on and off frequently such as compressor.....etc.,

User can set a band to prevent from the relay on and off frequently

■ **Relay energized delay [rY_rd] (Fig.3-②)**

Settable range from


0.0(second)~9(minutes)59.9(seconds);

The function is to avoid the miss action caused by noise. Sometime, the display value will swing caused by spark of contactor.....etc.. User can set a period to delay the relay energized.

■ **Relay de-energized delay [rY_Fd] (Fig.3-③)**

Settable range from

0.0(second)~9(minutes)59.9(seconds)



■ **Analogue Output Functions**

Please specify the output type either 0~10V or 4(0)~20mA in ordering code. The output low and high can be programmable which it's related with various display values. Reverse slope output is decided by reversing slope point positions.

■ **Output range selection ([RoLYP])**

● **Voltage output specified**

Programming : $\boxed{00-10}$ (0~10V) / $\boxed{00-5}$ (0~5V) / $\boxed{01-5}$ (1~5V)

● **Current output specified**

Programming : $\boxed{R4-20}$ (4~20mA) / $\boxed{R0-20}$ (0~20mA) / $\boxed{R0-10}$ (0~10mA)

■ **Low Output corresponds to Low display value [RoLS]**


Settable range: -19999~+29999;

Setting the Low Display value versus Low output range (as like as 4mA in $\boxed{R4-20}$).

■ **High Output corresponds to High display value [RoHS]**

Settable range: -19999~+29999;

Setting the High Display value versus High output range (as like as 20mA in $\boxed{R4-20}$).



*The interval between [RoHS] and [RoLS] should be with minimum over 20% of span; otherwise, it will reflect the less resolution of analogue output.

● **Fine Zero & Span Adjustment for Analogue Output**

Users can get Fine Adjustment of analogue output by front key on the meter. Please connect standard meter to the terminals of analogue output for measuring the output value. To press the front key(up or down key) of meter for adjusting and checking the output.

● **Fine Zero Adjustment for Analogue Output [RoZrO]: Settable range: -38011~27524;**

● **Fine Span Adjustment for Analogue Output [RoSPn]: Settable range: -38011~27524;**

■ **RS 485 Communication**

CS1 series can be used as Remote Terminal Unit (RTU) for monitoring and controlling in a SCADA (Supervisor Control And Data Acquisition) system.

● **Protocol:** Modbus RTU Mode

● **Baud Rate [bRUD]:**

Programmable 1200/2400/4800/ 9600/ 19200/ 38400

● **Data Bits:** 8 bits

● **Stop Bits:** Programmable 1 bit or 2 bits

● **Parity [PrLY]:** Programmable Even / Odd / None


● **Device Number [RdRE5]:** Settable 1~255

■ **Remote Display function [r5485]**

CS1 series has been built in an innovation function call remote display function.

When the [d5PLY] function set to be $\boxed{r5485}$, At meantime, the display is no longer according to the input signal. The PV screen will show the number from RS485 command & data.







In past, The meter normally receive 4~20mA or 0~10V from AO card or BCD card of PLC. We support a new solution by RS485 writing in so that can save cost of AO and wiring into PLC.




▶ The display will be shown $\boxed{----}$ when the data can not to be sent to the meter due to the communication error.

Field Calibration (for CS1-SG / CS1-PM / CS1-RS)


In past time, the engineers have to take a lot of time to adjust and calibrate meters or converters which the purpose of co-coordinating with zero and span of machinery structure for the Load Cell or Potentiometer measuring. Now, our CS1-SG, CS1-PM and CS1-RS with innovation functions against above to make the engineer operated easily and smoothly that it's called "Field Calibration". The procedures are described as below;

- Enter the right pass code [F.CdE] and access to the Field Calibration Level.
- Adjust the structures of machinery or & equipments to be "lower status".
- The low calibration of machinery structure is not need the exactly "zero" to calibrate, because of the "field calibration" function could be calibrate any lower point.
- Move next page to the [CALLo] and waiting for the value till stable, then pressed  Key to read the signal low of sensing device.
- Waiting for above reading stable (around 3~5seconds), press  Key again to complete the calibration lower point, and go to [CALL5].
- [CALL5] is the page of low scale setting that is relative to the calibration low point.
- Press  Key to next function index [CALH.].
- Adjust the structures of machinery or & equipments to be "higher status".
- The high calibration of machinery structure is not need the exactly "span" to calibrate because of the "field calibration" function could be calibrating any higher point.
- In [CALH.] page, waiting for the value till stable, then pressed  Key to to read the signal high of sensing device.
- Waiting for above reading stable (around 3~5seconds), Press  Key again to complete the calibration higher point, and go to [CALHS].
- [CALHS] is the page of high scale setting that is relative to the calibration high point.
- Press  Key to next functions [CSEL] to select [FELd].
- [CSEL](Calibration parameter selection): Field calibration wouldn't change the default calibration. After user completing the field calibration, it can also select default calibration if the user wants.
 - ▶ As the user finished the procedures of field calibration, the field calibration datum has been saved in EEPROM and it can't change the default(factory) calibration datum. Even the field calibration has been done, the user can still select either default calibration or field calibration.
 - ▶ If the user select field calibration, the [LoSc](step A-2) and [H.Sc](A-3) will be replaced by [CALL5] and [CALHS] which it can not to be changed by anyone. If user has to change the scaling, it's the only way to access field calibration level to set in [CALL5](step F-2) and [CALHS](step F-4).
 - ▶ After selecting the [DEFLt] or [FELd], please double check the [LoSc](step A-2) and [H.Sc](A-3) whether are corrected or not?

Please according to the numbers to do the field calibration (1 → 2 → 3 → 4 → 5 → 6)



Please according to the numbers to do the field calibration (1 → 2 → 3 → 4 → 5 → 6)



ORDERING INFORMATION

CS1-VA- DC/AC/TRMS - Input Signal - Optional Output - Aux. Powered

CODE	VOLT INPUT	CODE	CURRENT	CODE	OPTIONAL O/P	CODE	AXU. POWER
D	DC measuring	D	DC measuring	N	None	A	AC 115/230 V
A	AC measuring	A	AC measuring	R1	1 Relay	OPTION 4	
T	TRMS measuring	T	TRMS measuring	V	0(1) - 5 V / 0 - 10 V	ADH*	AC/DC 85-264V
V1	0 - 199.99 mV	A1	0 - 199.99 μ A	I	0 - 10mA 0(4)-20 mA	ADL*	AC/DC 20-56V
V2	0 - 1.9999 V	A2	0 - 1.9999 mA	8	RS 485		
V3	0 - 19.999 V	A3	0 - 19.999 mA	Relay, Analogue Output or RS485 Port can be selected one only			
V4	0 - 199.99 V	A4	0 - 199.99 mA				
V5	0 - 300.0 V	A5	0 - 1.9999 A				
V6	0 - 600.0 V	A6	0 - 1.0000 A				
VA	0-50 mV	A7	0 - 5.000 A				
VB	0-60 mV	A8	0 - 10.000 A				
VC	0-100 mV	AO	Specify A input				
VO	Specify V input						

* It means RoHS version.

CS1-PR- Input Signal - Optional Output - Excitation Supply - Aux. Powered

CODE	INPUT RANGE	CODE	OPTIONAL O/P	CODE	EXCIT. SUPPLY	CODE	AXU. POWER
A1	0(4) - 20mA / 0 - 10mA	N	None	N	None	A	AC 115/230V
AV	0-10V/0(4)-20mA(all in one)	R1	1 Relay	E24	DC 24V	OPTION 4	
AO	Specify A input	V	0(1) - 5 V 0 - 10 V	EO	Specify	ADH*	AC/DC 85-264V
VO	Specify V input	I	0 - 10 mA 0(4) - 20 mA			ADL*	AC/DC 20-56V
		8	RS 485	* ADH* & ADL* can not support the excitation supply			
		Relay, Analogue Output or RS485 Port can be selected one only.					

* It means RoHS version.

CS1-SG- Input Signal - Optional Output - Excitation Supply - Aux. Powered

CODE	INPUT	CODE	INPUT	CODE	OPTIONAL O/P	CODE	EXCITATION	CODE	AXU. POWER
S1	1.0mV/V	S8	10.0mV/V	N	None	E05	DC 5V	A	AC 115/230 V
S2	2.0mV/V	S9	20.0mV/V	R1	1 Relay	E10	DC 10V	OPTION 4	
S3	4.0mV/V	SA	40.0mV/V	V	0(1) - 10 mA 0 - 10 V	EO	Specify	ADH*	AC/DC 85-264V
SO	Specify			I	0 - 10 mA 0(4) - 20 mA			ADL*	AC/DC 20-56V
				8	RS 485	* ADH* & ADL* can not support the excitation supply			
		Relay, Analogue Output or RS485 Port can be selected one only							

* It means RoHS version.


CS1-PM- Input Signal - Optional Output - Aux. Powered

CODE	INPUT RANGE	CODE	OPTIONAL O/P	CODE	AXU. POWER
P1	0-50 Ω / - 2.0 K Ω	N	None	A	AC 115/230V
P2	0-2.0 K Ω / - 100.0 K Ω	R1	1 Relay	OPTION 4	
PO	Specify input	V	0(1) - 5 V 0 - 10 V	ADH*	AC/DC 85-264V
		I	0 - 10 mA 0(4) - 20 mA	ADL*	AC/DC 20-56V
		8	RS 485	* It means RoHS version.	
		Relay, Analogue Output or RS485 Port can be selected one only			

CS1-RS- Input Signal - Optional Output - Aux. Powered

CODE	INPUT RANGE	CODE	OPTIONAL O/P	CODE	AXU. POWER
R1	0.00 Ω - 200.00 Ω	N	None	A	AC 115/230V
R2	0.0 Ω - 2000.0 Ω	R1	1 Relay	OPTION 4	
R3	0.000 Ω - 20.000 K Ω	V	0(1) - 5 V 0 - 10 V	ADH*	AC/DC 85-264V
R4	0.00 Ω - 200.00 K Ω	I	0 - 10 mA 0(4) - 20 mA	ADL*	AC/DC 20-56V
RO	Specify	8	RS 485	* It means RoHS version.	
	The ranges can be changeable by dip switch.				
	Relay, Analogue Output or RS485 Port can be selected one only				

CS1-T



CODE	AXU. POWER
A	AC 115/230V
ADH*	AC/DC 85-264V
ADL*	AC/DC 20-56V

* It means RoHS version.

INSTALLATION


Please check the specification, wire diagrams and functions on the label of the meter before installation.




VOLT / CURRENT METERS	
MODEL CS1-VA-AA5-N-A	DATE 2008/8/25
INPUT 0~1.9999 Aac	S/N 78210010-56 14
DISPLAY 0~1.9999 Aac	
OUTPUT xx	SOURCE AC 115/230V
CHANG SHUAN www.csec.com.tw	

MODEL CS1-VA-AA5-N-A
INPUT 0~1.9999 Aac
DISPLAY 0~1.9999 Aac
OUTPUT xx SOURCE AC 115/230V

Dimensions & Panel Cut Out




Installation




Wiring Diagram

Please check the voltage of power supplied first, and then connect to the specified terminals. Herein, recommended that power supplied with protection by a fuse or circuit breaker to the meter.




Connector

CS1-VA: #A1~A3(Signal Input): 20A/300Vac, M3.5, 12~22AWG; Max torque: 13Kg-cm




Others: 10A 300Vac, M2.6, 16~22AWG, Max torque: 5Kg-cm Please use cord end terminal.




Please set the torque of automotive screwdriver to match the limited of terminals.


For input and RS485 wiring, it's recommended to use twin with shielding wire.




[CS1-VA Voltage / Current Meter Relay]




[CS1-RS Resistance Indicator]




Input connection




[CS1-PM Potentiometer Indicator]




[CS1-T Temperature Indicator]




[CS1-PR DC Process (10V/20mA) Indicator]




[CS1-SG Strain Gauge / Load Cell Indicator]




2 wire Transmitter connection



4(0)~20mA Input connection




Load Cell connection



OPERATIONS

Front Panel



Numeric Screens

0.8”(20.0mm) red high-brightness LED for 4 2/3 digital present value.

I/O Status Indication

- Relay Energized:** 1 square red LED
RL1 display when Relay 1 has been energized;
- RS485 Communication:** 1 square orange LED
COM will flash when the meter is receive or send data, and COM flash quickly means the data transient quicker.
- Max/Mini Hold indication:** 2 square orange LEDs
MH displayed: When the display function has been selected in Maximum or Minimum Hold function.

Stickers:

Each meter has a sticker what are functions and engineer label enclosure.

Functions stickers

HH	HI	LO	LL	D.L	D.H	DO	D.H	M.H	Tare
GO	Hi.H	Lo.H	R.PV	R.RS	M.RS	PV.H	BK1	BK2	BK3
DI	RST	DO1	DO2	DO3	DO4	DI1	DI2	DI3	

- Relay energized:**
 - Hi Hi Energized Lo Lo Energized
 - Hi.H Hi Energized & Latch Lo.H Lo Energized & Latch
- Front key functions:**
 - PV.H PV Hold Tare Tare DI Digital Input
 - M.RS Maximum or Minimum Reset
 - R.RS Reset fo Relay Latch

M/min	m/min	l on / U	L/min	l orr	M/rr	ng-cm	cmng	
mm	cm	M	KM	ft	Yard	ppm	ppb	C.C
g	KG	Ton	T-cm	NT-cm	PH	MPM	L	

- Operating Key:** 4 keys for Enter(Function) / Shift(Escape) / Up key / Down key

- Pass Code:** Settable range:0000~9999;

User must key-in the exactly pass code for access to [Programming Level]. Otherwise, the meter will return to measuring page. If user forgets the pass code, please contact with your service window.

- Function Lock:** There are 4 levels programmable.
 - None(nonE):** no lock at all. User can access to all level for checking and setting.
 - User Level(USEr):** User Level lock. User can access to User Level for checking, but can not setting.
 - Programming Level(EnG):** Programming level lock. User can access to programming level for checking, but can not setting.
 - ALL(RLL):** All lock. User can access to all level for checking but can not setting.

Front Key Function

The Down Key can be set to be function as like as **Relative PV(Tare) / PV Hold / Reset for max(mini) hold / Reset for relay energized latch.**

Ex. The [dntEY] function set to be REL.Pu in [rnpUt GrpUP]. When user presses DownKey, the PV will show relative value until press DownKey again.












Error Masage





















BEFORE POWER ON, PLEASE CHECK THE SPECIFICATION AND CONNECTION AGAIN.

SELF-DIAGNOSIS AND ERROR CODE:		
DISPLAY	DESCRIPTION	REMARK
ouFL	Display is positive-overflow (Signal is over display range)	(Please check the input signal)
-ouFL	Display is negative-overflow (Signal is under display range)	(Please check the input signal)
ouFL	ADC is positive-overflow (Signal is higher than input 120%)	(Please check the input signal)
-ouFL	ADC is negative-overflow (Signal is lower than input -120%)	(Please check the input signal)
EEP ↔ FAiL	EEPROM occurs error	(Please send back to manufactory for repaired)
Ri.CnG ↔ Pu	Didn't execute the calibrate of Input Signal	(Please process Calibrating Input Signal)
Ri.C ↔ FAiL	Input signal calibrated error	(Please check Calibrating Input Signal)
Ro.CnG ↔ Pu	Didn't execute the calibrate of output Signal	(Please process Calibrating Output Signal)
Ro.C ↔ FAiL	Output Signal calibrated error	(Please check Calibrating Output Signal)


Operating Key:

*Please access to the Programming Level to check and set the parameters when users start to run the meter

- **Operating Key:** 4 keys for  Enter(Function) /  Shift(Escape) /  Up key /  Down key
- The meter has designed operation similar as PC's   and . In any page, press  key means "enter" or "confirm setting", and press  key means "escape()" or "shift".
- In Programming Level, the screen will return to Measuring Page after do not press any key over 2 minutes, or press  for 1 second.

	Function Index	Setting Status
 (=  Enter/Fun key	(1) In any page, press  to access the level or function index (2) From the function index to access setting status	(3) Setting Confirmed, save to EEPROM and go to next function index
 (=  Shift key (Escape Key)	(1) In measuring page, press  for 1 second to access user level. (2) In function index, press  for 1 second to go back upper level. (3) In function group index, press  for 1 second to go back measuring page	(4) In setting status, press  to Shift the setting position. (5) In setting status, press  for 1 second to abort setting and go back this function index.
 (=  Up key	(1) In function index, press  to go back to previous function index	(2) In setting status for function, press  to select function (3) During number Setting, press  can roll the digit up
 (=  Down key	(1) In Function Index Page, press  will go to the next Function Index Page.	(2) In setting status for function, press  to select function (3) During number Setting, press  can roll the digit down.

OPERATING FLOW CHART: Please refer to operating manual for detail description



Pass Code

Programming Level


Default:1000
YES

Press for 1 sec. to back Measuring Page

INPUT GROUP	RELAY GROUP	ANALOGUE OUTPUT GROUP	RS485 GROUP
<p>INPUT GROUP</p> <p>INPuT GROUP</p> <p>↓ FUN ENT</p> <p>A-0 R.tYP: The function is for CS1-PR only. It'll be hidden for other models. R.tYP: Analogue Input type and range selection. [0-10] / [0-5] / [1-5] / [20-20] / [4-20] / [10-10]</p> <p>A-1 PuDP: Decimal Point of PV. [0.00] / [0] / [0.00] / [0.000] / [0.0000]</p> <p>A-2 LoSC: Low scale of PV. -19999~+29999</p> <p>A-3 HiSC: High scale of PV. -19999~+29999</p> <p>A-4 PuPro: Fine Low point Adjustment for PV display. -19999~+29999</p> <p>A-5 PuSPn: Fine High point Adjustment for PV display. -19999~+29999</p> <p>A-6 PSClr: Clear Fine Zero Span Adjustment for PV display. [nonE] / [PuPro] / [PuSPn] / [botH]</p> <p>Next Page</p>	<p>RELAY GROUP</p> <p>rELAY GROUP</p> <p>↑ FUN ENT</p> <p>B-1 rYStb: Start band for Relay energized. 0~9999 digits</p> <p>B-2 rYStd: Start delay time for Relay energized. 0:00.0~9(m):59.9(s)</p> <p>B-3 rYInM: Relay 1 energized mode. [oFF] / [Lo] / [Hi] / [LoHLd] / [HiHLd] / [do]</p> <p>B-4 rYIHY: Relay 1 Hysteresis. 0~5000counts</p> <p>B-5 rYIrd: Relay 1 energized delay time. 0:00.0~9(m):59.9(s)</p> <p>B-6 rYIfd: Relay 1 de-energized delay time. 0:00.0~9(m):59.9(s)</p>	<p>ANALOGUE OUTPUT GROUP</p> <p>Ro GROUP</p> <p>↓ FUN ENT</p> <p>D-1 Ro.tYP: Analogue Output type and range selection. [0-10] / [0-5] / [1-5] / [20-20] / [10-10]</p> <p>D-2 RoLS: the low point is relative to the lowest of Analogue output. -19999~+29999</p> <p>D-3 RoHS: the high point is relative to the highest of Analogue output. -19999~+29999</p> <p>D-4 RoPro: Fine Zero Adjustment for Analog Low Output. -38011~+27524</p> <p>D-5 RoSPn: Fine Span Adjustment for Analog High Output. -38011~+27524</p> <p>D-6 PSClr: clear fine Zero / Span Adjustment for Analogue output. [nonE] / [RoPro] / [RoSPn] / [botH]</p> <p>D-7 RoLnt: Analog Output High Limit. 0.00~110.00%</p>	<p>RS485 GROUP</p> <p>rS48S GROUP</p> <p>↓ FUN ENT</p> <p>E-1 AdRES: Device number of the meter. 1~255</p> <p>E-2 bRUD: Baud rate. [1200] / [2400] / [9600] / [4800] / [9600] / [19200] / [38400]</p> <p>E-3 Pr.tY: Parity. [nStb.1] / [nStb.2] / [odd] / [EvEn]</p>

A-7	dSPly Pu ↓ ↑	dSPly: Display Function for PV screen Pu / Fin.Hd / nR4Hd / 5485
A-8	LoCut 0.00 ↓ ↑	LoCut: Low Cut the PV -19999~+29999
A-9	Avg 5 ↓ ↑	Avg: Average update for PV 1(None)~99times
A-10	MAvg 1 ↓ ↑	MAvg: Moving Average update for PV 1(None)~10times
A-11	dFilt 0 ↓ ↑	dFilt: Digital filter 0(None)/1~99times
A-12	dnKEY nonE ↓ ↑	dnKEY: Down key function nonE / FELPu / PuHLd / FELPu / nESE / 9r5E
A-13	PCode 0000 ↓ ↑	PCode: Pass Code setting for access to Programming Level 0000~9999
A-14	FLoCL nonE ↓ ↑	FLoCL: Function Level Lock nonE / USEr / EnG / ALL

FIELD CALIBRATION (The function is only for CS1-SG / CS1-PM / CS1-RS)



■ Operating Steps:


■ User Level

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
POWER ON		Please check the specification and wiring diagrams firstly.	
88888	Self-diagnosis (LED All bright)		
CS IP r	Model CS tA: Amp / Volt CS tS: Resistance CS IP r: 0~(5)10V / 0(4)~20mA CS tG: Load Cell / Stran Gauge CS IP n: Potentiometer CS tE: Temperature		
uEr 10	Firmware version		
16888	Measuring Page		
Press for 1 second return to Measuring Page			
0-0-1 Pu	This page will be shown out when, when [dSPly](step A-07) function has not set to be Pu. Pu (Pv): Present Value;		
0-1 rY tSP	rY tSP (rY1.SP):Relay 1 Set-point Please confirm the energized mode of relay 1 before setting.	Settable range: -19999~+29999 Shift Up Down Enter	
0-2 rY rSt	rY rSt (rY.rSt): Reset for energizing latch of Relay; If the [rY tnd](step B-3) set to be H tHLd or LoHLd, and the present value(PV) reach to the condition of relay energizing that the relay will be energized and latching. At mean time, user can reset the relay latching in here.	Programmable: YES / no YES (Yes): reset the relay latching. no (No): abort to reset the relay latching. Up Down Enter ■ Be careful, the relay has been energizing and latching again even user had set here to reset the relay latching.. if the PV still reach to the condition of relay energized,	
0-3 n in	n in (Min): the Minimum value of PV saving; The meter will save the minimum of PV during power on, until reset in [n rSt](step 0-5). It will save newest minimum after reset.	Review only	
0-4 n rY	n rY (Max): the Maximum value of PV saving; The meter will save the maximum of PV during power on, until reset in [n rSt](step 0-5). It will save newest maximum after reset.	Review only	
0-5 n rSt	n rSt (M.rSt): reset the saved value of Maximum & Minimum; The values of maximum and minimum can be reset in here. It will save newest maximum and minimum after reset.	Programmable: YES / no YES (Yes): to reset the saved value of maximum and minimum. no (No): abort to reset the saved values of maximum and minimum.	
NEXT PAGE			

0-6		Model of the meter CS VA (CS1-VA): Volt/Currnt CS PR (CS1-PR): DC 0~10V / 4~20mA CS SG (CS1-SG): Strain Gauge / Load Cell CS PM (CS1-PM): Potentiometer CS RS (CS1-RS): Resistance CS T (CS1-T): Rtd /Thermocouple uEr 1.0 (Ver 1.0): Firmware version	Review only It will be announce in our website www.adtek.com.tw , when it has been version changed.	
0-0-1		Cyclic to first page		
Press for 1 second to back to Measuring Page in any page.				









Programming Level








INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
16888	MEASURING PAGE		
 P.Code Default:1000	Enter the pass code to access Programming Level	If user wants to change the pass code, please go to step A-13 to set. Please remind the new pass code.	
 Pass Code	Enter the pass code to access programming level.		
Press for 1 second to back Measuring Page			





Input Group

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
inPUt	INPUT GROUP INDEX PAGE	In following pages, press for 1 second to back INPUT GROUP INDEX PAGE.	
 GroUP A.i.tyP R4-20 u.0-10	The function is only for CS1-PR A.i.tyP (Ai.tyP): Analog input type & range selection There are 3 terminals for mA and V input, if user selects ordering code in input for "AV" from input. Please confirm the wiring is correct or not to set.	Programmable: u.0-10(0~10V) / u.0-5(0~5V) / u.1-5(1~5V) / R0-10(0~10mA) / R0-20(0~20mA) / R4-20(4~20mA) ▲Up ▼Down Enter	
 Pu.dP 0 0.0000	Pv.dP (Pv.dP): Decimal Point of PV	Programmable: 0 / 00 / 000 / 0000 / 0.0000 ▲Up ▼Down Enter	
NEXT PAGE			

<p>A-2</p> 	<p>Lo.SC (Lo.SC): Low scale of PV</p> <p>CS1-SG/PM/RS: If the field calibration has been done and then the [CSEL] (Calibration parameter selection) selected to be FELD (field calibration), the [Lo.SC] will be replaced by [ALLS], and it can not to be set.</p>	<p>Programmable: -19999~29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p> 
<p>A-3</p> 	<p>Hi.SC (Hi.SC): high scale of PV</p> <p>CS1-SG/PM/RS: If the field calibration has been done and then the [CSEL] (Calibration parameter selection) selected to be FELD (field calibration), the [Hi.SC] will be replaced by [ALHS], and it can not to be set.</p>	<p>Settable range: -19999~29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>
<p>A-4</p> 	<p>Pv.Zro (Pv.Zro): Fine Adjustment low point for PV display;</p> <p>For Zero & Span of PV, users can get the "Fine Adjustment" by front key. It's an easy way to "Just Key-In" the value that the user wants to show in the current input signal. Especially, the [Pv.Zro] & [Pv.SPn] are not only in zero & span of PV, but also any lower point for [Pv.Zro] & higher point for [Pv.SPn]. The meter will be linear for full scale.</p>	<p>Settable range: -19999~+29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p> 
<p>A-5</p> 	<p>Pv.SPn (Pv.SPn): Fine Adjustment high point for PV display;</p> <p>It's same function as like as [Pv.Zro].</p>	<p>Settable range: -19999~+29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>
<p>A-6</p> 	<p>Z.S.Clr (Z.S.Clr): Clear Fine Adjustment of Low / High points for PV display;</p>	<p>Programmable:</p> <p>nonE (None): Do not clear the fine adjustment of Low / High.</p> <p>Pv.Zro (PV.Zro): To clear the fine adjustment Low.</p> <p>Pv.SPn (PV.SPn): To clear the fine adjustment High</p> <p>botH (Both): To clear the fine adjustment of Low and High.</p> <p>▲Up ▼Down FUN ENT Enter</p>
<p>A-7</p> 	<p>dSPly (dSPly): Display Function for PV screen</p> <p>When the [dSPly] function set to be RS485, At meantime, the input signal (PV) no longer display now. The PV screen will show the number from RS485 command & data directly. The data(number) will be same as PV that it will compare with set-point, analogue output and down key functions are correspondent to control analogue output, relay energized and so on.</p>	<p>Programmable:</p> <p>Pv (PV): shows PV</p> <p>Min.Hd (Min.Hd): Minimum Hold of PV</p> <p>MAX.Hd (MAX.Hd): Maximum Hold of PV</p> <p>RS485 (RS485): Remote displayed from RS485 command of master.</p> <p>▲Up ▼Down FUN ENT Enter</p>
<p>NEXT PAGE</p>		

<p>A-8</p> 	<p>Lo.CUt (Lo.CUt): Low Cut the PV</p> <p>if set the positive value (X1) here to display "0" which it expressed to be low-cut the PV between "+X1 (plus)" & "-X1(minus)" /absolute value</p> <p>$PV \leq \text{Setting value}$, the display will be 0.</p> <p>If set the negative value (X2) here to display "X2" which it expressed to be low-cut the PV that it's under the X2 setting value;</p> <p>$PV < \text{Setting value}$, the display will be <u>X2(Setting value)</u>.</p>	<p>Settable range: -19999~+29999</p> <p>◀Shift ▲Up ▼Down ▶Enter</p> <p>Low Cut set to be +0.50</p>  <p>Low Cut is set for 0.50, if the PV is from -0.50~+0.50, that display will be 0.</p> <p>Low Cut set to be -0.10</p>  <p>Low Cut is set for -0.10, if the PV is under (≤ -0.10), that display will be -0.10.</p>	
<p>A-9</p> 	<p>AvG (AvG): Average update for PV</p> <p>The meter's sampling is 15cycle/sec</p> <p>If the [AvG](Average) set to be [3] to express the display update with 5 times/sec.</p> <p>The meter will calculate the sampling 1-3 and update the display value. At meantime, the sampling 4-6 will be processed to calculate.</p>	<p>Settable range:</p> <p>1(no function)~99 times</p> <p>◀Shift ▲Up ▼Down ▶Enter</p>	
<p>A-10</p> 	<p>M.AvG (M.AvG): Moving Average update for PV</p> <p>The meter's sampling is 15cycle/sec. If the [M.AvG](Moving Average) set to be [3] expressed the display update with 15 times/sec.,</p> <p>In the first updated display value will be same as average function. In the next updated display value, the function will get the new fourth sample (sample 4) then throw away the first sample (sample 1) that the newest 3 samples(sample 2,3,4) will be calculated for the updated display value.</p>	<p>Settable range:</p> <p>0(no function)/1~10 times;</p> <p>◀Shift ▲Up ▼Down ▶Enter</p>	
<p>A-11</p> 	<p>d.FiLt (d.FiLt): Digital filter</p> <p>The digital filter can reduce the influence of spark noise by magnetic of coil.</p> <p>If the values of samples are over digital filter band(fixed in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.</p>	<p>Settable range:</p> <p>0(no function)/1~99 times.</p> <p>◀Shift ▲Up ▼Down ▶Enter</p>	
<p>A-12</p> 	<p>dn.key (dn.key): Down key function</p> <p>Users can set the ▼down key of front panel to be the functions as like as Relative PV(Tare) / PV Hold / Reset for max(mini) hold / Reset for relay energized latch.</p>	<p>Programmable:</p> <p>nonE (None): no fuction</p> <p>rEL.Pv (rEI.Pv): Relactive PV</p> <p>Pv.HLd (Pv.HLd): PV hold</p> <p>nrSt (M.rST): Reset for Max./Mini hold</p> <p>ryrSt (rY.rST): Reset for Relay energized latch</p> <p>▲Up ▼Down ▶Enter</p>	
<p>NEXT PAGE</p>			

<p>A-13</p> 	<p>P.CoDE (P.CoDE): Pass Code setting for access to programming level</p> <p>Please remind and write down the new pass code so that access to programming level.</p>	<p>Settable range: 0000~9999</p> <p>◀Shift ▲Up ▼Down ▶Enter</p>
<p>A-14</p> 	<p>F.LoCk (F.LoCk): Function level Lock</p> <p>There are 4 levels programmable for lock that the function is to avoid miss-setting.</p>	<p>Programming:</p> <p>nonE (None): no lock at all. User can access to user level for checking and setting.</p> <p>USEr (User Level): User level lock. User can access to user level for checking, but can not setting.</p> <p>EnG (Programming Level): Programming level lock. User can access to programming level for checking, but can not setting.</p> <p>ALL (All Level): All lock. User can access to all level for checking, but can not setting.</p> <p>▲Up ▼Down ▶Enter</p>

■ Relay Group (The group will not be displayed except the relay function is to be specified)

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
<p>RELAY GROUP</p> <p>↓ FUN ENT</p> <p>B-1</p> <p>rY5b</p> <p>0000</p> <p>00</p> <p>9999</p> <p>↓ FUN ENT Nest Page</p>	<p>RELAY GROUP INDEX PAGE</p> <p>Fig.2</p>	<p>In following pages, press ◀ for 1 second to return the RELAY GROUP INDEX PAGE.</p> <p>Settable range: 0~9999 digits</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>B-2</p> <p>rY5d</p> <p>0000</p> <p>0000</p> <p>9.999</p> <p>↓ FUN ENT Nest Page</p>	<p>rY5d (rY.Sd): start delay time for Relay energized</p>	<p>Settable range: 0:00.0~9(M):59.9(S)</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>B-3</p> <p>rY1Md</p> <p>H.</p> <p>H.</p> <p>H.HLd</p> <p>↓ FUN ENT Nest Page</p>	<p>rY1Md (rY1.Md): Relay 1 energized mode</p> <p>Hi / Lo Relay Energized</p> <p>Relay Energized Latch & Reset</p>	<p>Programmable:</p> <p>oFF (Off): Turn off the Relay and indication LED.</p> <p>Lo (Lo): Low Level Energized; Relay will energize when PV < Set-Point.</p> <p>Hi (Hi): High Level Energized; Relay will energize when PV > Set-Point.</p> <p>H.HLd (Hi.HLd) / Lo.HLd (Lo.HLd): High / Low Level energize and latch; As the PV Higher (or lower) than set-point, the relay will be energized to latch except manual reset by from key in [User Level], or down key function has be set to rYr5E and be pressed.</p> <p>▲Up ▼Down FUN ENT Enter</p>	
<p>B-4</p> <p>rY1HY</p> <p>0000</p> <p>00</p> <p>5000</p> <p>↓ FUN ENT Nest Page</p>	<p>rY1HY (rY1.HY): Relay 1 Hysteresis</p> <p>Energized / De-energized Delay & Hysteresis</p>	<p>Settable range: 0~5000 digits</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>B-5</p> <p>rY1rd</p> <p>0000</p> <p>0000</p> <p>9.999</p> <p>↓ FUN ENT Nest Page</p>	<p>rY1rd (rY1.rd): Relay 1 energized delay time</p>	<p>Settable range: 0:00.0~9(M):59.9(S)</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>B-6</p> <p>rY1Fd</p> <p>0000</p> <p>0000</p> <p>9.999</p> <p>↓ FUN ENT Nest Page</p>	<p>rY1Fd (rY1.Fd): Relay 1 de-energized delay time</p>	<p>Settable range: 0:00.0~9(M):59.9(S)</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	

■ Analogue Output Group (The group will not be displayed except the AO function is to be specified)

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
<p>R_o</p> <p>GrOUP</p> <p>FUN ENT ↓</p>	<p>AO GROUP INDEX PAGE</p>	<p>In following pages, press ◀ for 1 second to return the AO GROUP INDEX PAGE.</p>	
<p>D-1</p> <p>R_otYP</p> <p>R4-20</p> <p>U0-10</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p>	<p>R_otYP (Ao.tYP): Analogue Output type and range selection;</p> <p>Analogue output type had been fixed in mA or V as customer ordering requested. Therefore, the type selection is only for the ranges in same type(Voltage or Current).</p>	<p>Programmable:</p> <p>Voltage Output:</p> <p>U0-10(0~10V) / U0-5(0~5V) / U1-5(1~5V)</p> <p>Current Output:</p> <p>R0-10(0~10mA) / R0-20(0~20mA) / R4-20(4~20mA)</p> <p>▲Up ▼Down FUN ENT Enter</p>	
<p>D-2</p> <p>R_oL5</p> <p>00000</p> <p>5000</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p>	<p>R_oL5 (Ao.LS): the Low point is relative to Analogue Output low;</p> <p>To set the lower display value versus low output range (as like as 4mA in R4-20) Ex. Output range set to be R4-20 (4~20mA) is relative to display 0~199.99. User can set the [R_oL5] (Ao.LS) to be 5000. At meantime, the output signal will be 4mA when the present value is 50.00.</p>	<p>Settable range: -19999~29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>D-3</p> <p>R_oH5</p> <p>19999</p> <p>15000</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p> <p>will be changed according to H.S.C set.</p>	<p>R_oH5 (Ao.HS): the High point is relative to Analogue Output high;</p> <p>To set the higher display value versus high output range (as like as 20mA in R4-20) Ex. Output range set to be R4-20 (4~20mA) is relative to display 0~199.99. User can set the [R_oH5] (Ao.HS) to be 15000. At meantime, the output signal will be 20mA when the present value(PV) is 150.00.</p>	<p>Settable range: -19999~29999</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>D-4</p> <p>R_oZrO</p> <p>00000</p> <p>47233</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p>	<p>R_oZrO (Ao.Zro): Fine Zero Adjustment for Analog Low Output;</p> <p>Users can get Fine zero Adjustment for analogue output by front key. Please connect standard meter to the terminal of analogue output for measuring the output value. To press the front key(up or down key) to adjust and check the output of meter.</p>	<p>Settable range: -38011~27524</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>D-5</p> <p>R_oSPn</p> <p>00000</p> <p>32767</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p>	<p>R_oSPn (Ao.SPn): Fine Span Adjustment for Analog high Output;</p> <p>Users can get Fine span Adjustment for analogue output by front key of the meter as like as [R_oZrO] (Ao.Zro).</p>	<p>Settable range: -38011~27524</p> <p>◀Shift ▲Up ▼Down FUN ENT Enter</p>	
<p>D-6</p> <p>Z.S.Clr</p> <p>nonE</p> <p>both</p> <p>FUN ENT ↻</p> <p>FUN ENT Nest Page</p>	<p>Z.S.Clr (Z.S.Clr): Clear the Fine Zero / Span Adjustment for Analog Output</p>	<p>Programmable:</p> <p>nonE(None): Do not clear</p> <p>R_oZrO(Ao.Zro): Clear low adjust</p> <p>R_oSPn(Ao.SPn): Clear high adjust</p> <p>both(both): Clear low & high adjust</p> <p>▲Up ▼Down FUN ENT Enter</p>	
<p>NEXT PAGE</p>			

D-7 AoLnt

110.00

100.00

100.00

Next Page

AoLnt (Ao.LMt): Analog Output High Limit

Set Scaling: [Lo.SC]: 000, [Hi.SC]: 19999

Output: [AoLS]: 5000 (Display value Low); [AoHS]: 15000 (Display value High); [AoLnt]: 80.00% (of Output Range)

SCALE

[Hi.SC] 19999

[AoHS] 15000

[AoLS] 5000

[Lo.SC] 000

OUTPUT

0.00% 50.00% 80.00% 100.00%

[AoLnt]

Settable range: 0.00~ 110.00% of FS

Shift Up Down Enter


RS485 Group (The group will be hidden, if the RS485 function is not to be specify)

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
r5485 GROUP	RS485 GROUP INDEX PAGE	In following pages, press Left for 1 second to return the RS485 GROUP INDEX PAGE.	
E-1 AdRES	AdRES (Address): Device number of the meter.	Settable range: 1~255 Shift Up Down Enter	
E-2 bAUd	bAUd (bAUD): Baud rate	Programmable: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 Up Down Enter	
E-3 Prity	Prity (PritY): Parity	Programmable: nStb.1 (n.Stb.1): None, 1 stop bit nStb.2 (n.Stb.2): None, 2 stop bit odd (odd): odd EuEn (Even): Even Up Down Enter	

Field Calibration Group [CS1-SG / CS1-PM / CS1-RS only]


Please according to the numbers to do the field calibration (1 → 2 → 3 → 4 → 5 → 6)

Potentiometer 0~1.0Kohm



Please according to the numbers to do the field calibration (1 → 2 → 3 → 4 → 5 → 6)














Standard Weight



INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
16888	Measuring Page		
Enter PCode	Pass Code Page		
NEXT PAGE			

		Pass Code Page for Field Calibration Level	Enter the exactly pass code of the meter to access the Field Calibration Level. Otherwise, it will be turning back to measuring page.
Adjust the structure of machinery to be a lower signal output status(or any lower status).			
		CALLo (CAL.Lo): Field Calibration Low. The low calibration is not need the exactly "zero" to calibrate because of the "field calibration" function could be calibrate any lower point.	<ul style="list-style-type: none"> ▶ Waiting for the value till stable, pressed Key to read signal low of sensing device. ▶ Waiting for above reading stable (around 3~5seconds), press Key again to complete the calibration lower point, and go to [CALLS].
		CALLS (CAL.LS): the value to be set is relative to Field Calibration low point.	Settable range: -19999~29999 Shift Up Down Enter
Adjust the machinery structure to the higher signal output status(or any higher status).			
		CALHi (CAL.Hi): Field Calibration High. The high calibration is not need the exactly "span" to calibrate because of the "field calibration" function could be calibrating any higher point.	<ul style="list-style-type: none"> ▶ Waiting for the value till stable, pressed Key to read signal high of sensing device. ▶ Waiting for above reading stable (around 3~5seconds), press Key again to complete the calibration higher point, and go to [CALHS].
		CALHS (CAL.HS): the value to be set is relative to Field Calibration high point.	Settable range: -19999~29999 Shift Up Down Enter
		CSEL (C.SEL): Calibration parameter selection; As the user finished the procedures of field calibration, the field calibration datum has been saved in EEPROM and it can't change the default(factory) calibration datum. Even the field calibration has been done, the user can still select either default calibration or field calibration.	Programmable: DEFLE (default): factory calibration points and factors FELD (field): field calibration points and factors Up Down Enter <ul style="list-style-type: none"> ■ If the user select field calibration of the [LoSC](step A-2) and [HiSC](step A-3) will be replaced by the [CALLS] and [CALHS] which it can not to be change by anyone. If user has to change the scaling, it's the only way to access field calibration level to set in [CALLS] (step F-2) and [CALHS](step F-4). ■ Please double check the [LoSC](step A-2) and [HiSC](step A-3) whether are correct after selection the DEFLE or FELD.
Go back to Measuring Page			


■ TROUBLE SHOOTING

Display Issue:		
PROBLEM	CHECKING LIST	REMEDY
Display shows 	1. Check if the input signal type (V/A/mA..) of meter is matching with signal in field or not.	Please change another meter that is matching in field. ▶ For CS1-PR, input range can be programmed in same type(mA or V). Please check the [RANG] (A-00) in [INPUT GROUP].
	2. Check if the input signal is over +120% of input high limit or -120% of input low limit.	Please change another meter that is matching in field.
	3. Check if the wirings are correct and secure or not.	A. Please check carefully the connection diagram of label on the meter. B. Please use the terminals (Y, Ring or cord end terminal) to avoid the risk of insecure.
Incorrection display value or out of accuracy	1. Check if the input signal type (V/A/mA..) or range of meter is matching with signal in field or not.	Please change another meter that is matching in field.
	2. Check if the settings of high and low scale are correct or not.	Please check the [HIGH] (A-03) and [LOW] (A-02) in [INPUT GROUP].
	3. Check if the high and low fine adjustments for PV are changed or not.	Please check the [PUSH] (A-05) and [PUSH] (A-04) in [INPUT GROUP]. The values can be clear in [PUSH] (A-06).
	CS1-PR: 4. Check if the input signal range of meter is matching with signal in field or not.	Please check the [RANG] (A-00) that has to match the signal in field.
	CS1-SG/CS1-PM 5. Check if the field calibration is matching with sensor in field or not.	Please check the [CALIB] (F-02) and [CALIB] (F-04) that has to match the measuring range of sensor.
Jittery Display	1. Check if the input signal is jittery.	A. If the input signal is jittery continuously, please set higher value in [RANG] (A-09) or [RANG] (A-10) B. If the input signal is jittery uncertain period that caused by the inductive load actions, please set higher value in [dFILT] (A-11) C. Please do not lay the wires of input together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.
	2. Check if the input signal is stable.	A. If the input signal is jittery continuously, please set higher value in [RANG] (A-09) or [RANG] (A-10) B. If the input signal is jittery uncertain period that caused by the inductive load actions, please set higher value in [dFILT] (A-11) C. Please connect an isolation transformer as close as meter in power lines.
Display shows 	Check display function [dSPLY]. It's maybe to be set to 	Please check the [dSPLY] (A-07) in [INPUT GROUP] and change the function set from  to  .
display value doesn't change	1. Check display function [dSPLY]. It's maybe to be set to  (maximum hold) or  (minimum hold)	Please check the [dSPLY] (A-07) in [INPUT GROUP] and change the function set from  or  to  .
	2. Check the LED of front key function is bright or not. It's maybe to be set to  , and has been doing the function.	A. Please press the down key again to reset the function. B. Please check the [dKEY] (A-12) in [INPUT GROUP] and change the function set from  to  .

Relay Output Issue:		
PROBLEM	CHECKING LIST	REMEDY
The parameters of Relay dosen't shown	Check if the label of meter for detail specification.	A.Please check the product number and output(O/P:_____) description again to confirm the relay output is specify or not. B.Please send back to our sales window, or order another product with relay function.
Relay cans not action.	The relay energized LED doesn't bright	
	1.Check the energized mode	Please check the [rY lnd](B-03) in [rELAY GrOUP]
	2.Check the delay time and delay band of start delay function.	Please check the [rY5b](B-01) is too wide and [rY5d](B-02) is too long in [rELAY GrOUP] or not.
	3. Check the energized delay time	Please check the [rY lrd](B-05) is too long in [rELAY GrOUP] or not.
	The relay energized LED dose bright	
	1.Check the wiring of relay output	According to the label of meter, please check again the connection wire of relay. Be careful to check the number of relay is matching the setting.
	2.Check the voltage of supply power	

Analogue Output Issue:		
PROBLEM	CHECKING LIST	REMEDY
Incorection analogue output value or out of accuracy	1.Check if the output signal type (V/A/mA..) or range of meter is matching with signal in field or not.	A.Please check the product number and output(O/P:_____) description again to confirm the analogue output is specify or not. If it does not specify, please send back to our sales window, or order another product with analogue function. B.Please confirm the output type is correct and check the range in [RoltYP](D-01) of [Ro GrOUP]
	2. Check the Analogue output highand low setting.	A.Please check the [RAl 5](D-02) and [RAlH5](D-03) in [Ro GrOUP].
Jittery Analogue Output	Analogue output is according to the display	
	1.Check if the display is jittery	A.If the input signal is jittery continuously, please set higher value in [RUG](A-09) or [hURUG](A-10) B.If the input signal is jittery uncertain period that caused by the inductive load actions, please set higher value in [dF iLt](A-11) C.Please does not lay the wires of input together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.
	2.Check if the display is stable	Please do not lay the wires of output together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.

RS485 Communication Issue:		
PROBLEM	CHECKING LIST	REMEDY
Can not link	Check if the LED of RS485 dosen't bright.	A.Please check the [RdrE5](E-01) \ [bRUd](E-02) and [Pr iEY](E-03) in [r5485 GrOUP] have to match the Host. B.Please check the wiring A(+) and B(-) are corrent. C.If user uses a converter (RS485/RS232 or RS485/USB.), please check the setting and wiring of converter is correct. D.Please check the protocol of host is Modbus RTU Mode
Reply wrong data from the meter	1.Check if the LED of RS485 dose bright, but no reply.	A.Please confirms the CHECH SUM program is correct. B.Please check the interval of each command has to over 3.5byte.

	2. Check if the LED of RS485 dose bright, but reply Error.	<p>A.Please check the address table of RS485 to make sure that is right address.</p> <p>B.Please checks the start address and data format are correct.</p> <p>C. Please do not lay the wires of RS485 together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.</p>
Display shows 	In the case, the [d5PL4](A-07) has been set to be [5485], and the master can not sent the data to the meter.	<p>A.Check the communication software of master.</p> <p>B.Please check the wiring is correct.</p>

■ RS485 MODBUS RTU MODE

■ Modbus RTU Mode protocol

1. Function 03H (Read Holding Registers)

Request Data Frame; EX: Read the data of display value(0000H starts from 1 Word)

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	01H	84H	0AH

Response Data Frame; EX: The response value is "0"

SLAVE Address	FUNCTION	Byte count	Data Hi	Data Lo	CRC Lo	CRC Hi
01H	03H	02H	00H	00H	B8H	44H

Request Data Frame (EX: Continue to request the data of 10 points)

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	0AH	C5H	CDH

Response Data Frame

SLAVE Address	FUNCTION	Byte count	Data(1) Hi	Data(1) Lo	Data(10) Hi	Data(10) Lo	CRC Lo	CRC Hi
01H	03H	14H	00H	00H	01H	00H	--	--

2. Writing Command by Function 06H (Preset Single Register)

Request Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	00H	00H	02H	08H	0BH

Response Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	00H	00H	02H	08H	0BH

■ ADDRESS TABLE ****Address number are Hexadecimal**

■ User level

Name	Address	Range	Explain	Initial	Write/Read	Note
P_U	0000h	-19999~29999	Present Value		R	
P_UH_d	0001h	-19999~29999	PV Hold		R	
n_{in}	0002h	-19999~29999	The Minimum of PV		R	
n_{Max}	0003h	-19999~29999	The Maximum of PV		R	
SYSTEM STATUS	0004h		SYSTEM STATUS bit0 =1 EEP fail; bit1 =1 Input calibration fail; bit2 =1 Input calibration NG; bit3 =1 Analogue Output calibration fail; bit4 =1 Analogue Output calibration NG		R	
n_rSt	0005h	0~1	Reset Maximum & Minimum Value 0 :No 1 :Yes	0	R/W	
r_{S485}	0006h	-19999~29999	PV showing from RS485 command(data)	0	R/W	

■ Programming Level

[Input Group]						
Name	Address	Range	Explain	Initial	Write/Read	Note
RESERVED			No use unless CS1-PR			
ANLTYP	0007h	0~5	The address is for CS1-PR only Analogue Input Type 0: 0~10V 1: 0~5V 2: 1~5V 3: 0~20mA 4: 4~20mA 5: 0~10mA	4	R/W	
PUDP	0008h	0~4	PV Decimal Point 0: 00000 1: 0000.0 2: 000.00 3: 00.000 4: 0.0000	0	R/W	
LSCL	0009h	-19999~29999	Low Scale	0	R/W	
HSCL	000Ah	-19999~29999	High Scale	19999	R/W	
PVZERO	000Bh	-19999~29999	PV ZERO	0	R/W	
PVSPAN	000Ch	-19999~29999	PV SPAN	0	R/W	
CLRST	000Dh	0~3	The clear of PV_ZERO and PV_SPAN 0: None 1: PV_ZERO 2: PV_SPAN 3: Both	0	R/W	
DISPLY	000Eh	0~3	Display Mode 0: PV 1: Minimum Hold 2: Maximum Hold 3: RS485	0	R/W	
LOCUT	000Fh	-19999~19999	Low Cut	0	R/W	
AUC	0010h	1~99	Average	5	R/W	
DFILT	0011h	0~99	Digital Filter	0	R/W	
PCode	0012h	0000~9999	Pass Code	1000	R/W	
FLCK	0013h	0~3	Function Lock 0: none 1: User Level 2: Engineer Level 3: All	0	R/W	
[RS485 Group]						
Name	Address	Range	Explain	Initial	Write/Read	Note
ADDRS	0014h	1~255	RS485 address	1	R/W	
BAUD	0015h	0~5	RS485 baud rate 0: 1200 1: 2400 2: 4800 3: 9600 4: 19200 5: 38400	3	R/W	
PRITY	0016h	0~3	RS485 parity 0: n-8-1 1: n-8-2, 2: odd, 3: even,	1	R/W	

■ DISCLAIMS

The information in this manual has been carefully checked and is believed to be accurate. ADtek Instruments Co., Ltd. assumes no responsibility for any infringements of patents or other rights of third parties, which may result from its use.

ADtek assumes no responsibility for any inaccuracies that may be contained in this document, and make no commitment to update or to keep current the information contained in this manual.

ADtek reserves the right to make improvements to this document and/or product at any time without notice.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form of or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of ADtek Instruments Co., Ltd.

■ Trademark

The names used for identification only maybe registered trademark of their respective companies.

Copyright © 2013 ADtek Instruments Co., Ltd. All rights reserved.

Printed in Taiwan.

Welcome to visit our online

www.adtek.com.tw www.csec.com.tw